

Preface

- This “Operation Instruction Manual” is given with each machine, please keep this manual for your reference at any time.
- Please read this instruction manual carefully before you operate this machine.
- Due to technology upgrading and product special requirement, machine may be different from instruction manual partially, please be subject to actual machine, we will add additional explanation as much as possible.
- When the equipment is working normally, please keep some space in front of and at the back of the equipment, which is required for operation and maintenance. Besides, please do not block heat emission of the equipment.
- Equipment operating environment: temperature:5~25℃, relative humidity:20~95%, place with no direct sunlight, no condensation, no splashing water, oil and chemical.
- The technician who operates and repairs this machine must be able to use computer.
- The computer that is equipped for the machine can be only used for this equipment, can not be used for other purposes; it is strictly forbidden to connect any other movable memory device with virus with the machine to avoid damaging control system.
- The USB flash disk that is given with machine must be protect from virus, do not use it on other computer casually.
- For the sake of people's safety, when the machine is running, please do not open the front and back movable door and reach out your body into the machine or move close to the machine without taking any safety protections, otherwise, it will bring unnecessary personnel injury.
- Turning the power on and off repeatedly will be one reason of machine breakdown. After turning off power, you need to wait for at least 20 seconds before you can turn on the power again.
- Do not let the machine suffer from impact or strong vibration, otherwise it will cause machine breakdown.
- When you shut off the machine power, please do it according to following sequence; if you do not follow the sequence and shut off the power or restart directly, the data can not be saved completely, it will also cause damage to hard disk. Exit/Shut off procedure: exit from application program—→exit from Windows —→ turn off power
- If you need to temporarily stop using the machine, please keep the machine in the environment as follows:temperature:5~25℃, relative humidity:20~95%, place

with no direct sunlight, no condensation, no splashing water, oil and chemical.

In order to avoid dust, you can cover up the machine(for example, put a cover), but must be moisture-proof.

- If not understand, please contact us, please must not operate blindly.

Note: please pay attention to affairs mentioned above!

Chapter 1 Overview

S4000 series of machines can insert various kinds of tape packed components (electrolytic capacitor, porcelain capacitor, etc). The machine station can dispense material on special W-shape carrier clip, then carrier clips will be transferred to inserter and jump wire and various kinds of electronic component and jump wire will be inserted on PCB automatically, also showing the non performing status on display and detecting missing component, which shows the machine is a automatic equipment with high precision and performance.

One outstanding feature of this machine is: it is able to insert cylindrical jump wire to PCB directly without sequencing again, which can save 1/3 of jump wire. Supported by the self-developed software, the machine is featured with three functions all in one: it can not only insert jump wire alone, but also can insert axial electronic component alone, and can insert jump wire and axial component together as well. With one machine and one operator, it can achieve the output that equals to the yield of 40 workers inserting component manually.

1. Machine Technical Specifications:

Item	Technical Specifications
Insertion Rate	24000 pcs/hr
Non Performing Rate	Less than 300PPM
Insert Theta	Parallel 0° ,90° ,180° , 270°

Component Span	Dual span 5.0mm-20mm
PCB size	Min:50mm*50mm; Max: 450mm*450mm
PCB thickness	0.79-2.36mm
Component types	Axial tape packed material, such as capacitor, transistor, diode, resistor, blown fuse.
Clinch length	1.2-2.2mm(adjustable)
Clinch degree	0-35° (adjustable)
Station quantity	60 stations(recommended),optional (10-100 stations)
Machine size (length×width×height)	Main unit 1700mm×1300mm×1600mm
Station size(length×width×height)	510mm×1000mm×1410mm(10 stations)
Main unit weight	1500KG
Auxiliary unit weight	750KG (40 stations)
Power supply	220V,AC(single phase), 50/60HZ, 2.0KVA;
System protection	Uninterruptible power supply (UPS) configuration, run 15 minutes after power outage
Working power	1.6KW (Energy Saving)
Air pressure	0.6--0.8MPA
Air consumption	0.3m ³ /minute

2. Machinery Part:

1) Machine stand

Based on scientific calculation, the machine stand structure is made of square iron tube welded with iron plate, then went through aging treatment, which ensures good rigidness and stability. The four corners of machine are installed with vibration-proof feet, whose height can be adjusted to achieve proper leveling of machine.

2) X, Y worktable assembly

This machine inserts component to each areas of PCB by moving the worktable, where the PCB is placed.

Each worktable assembly uses two hard steel shaft as rail, uses ball lead screw and servo motor in the middle to drive. Lead screw nut is fixed with platform board, and the two ends of lead screw is fixed, the motor is connected with it through timing belt.

Motor drives lead screw to rotate, and lead screw drives lead screw nut and worktable to move in a straight line.

On X, Y worktable assemblies, there are positive and negative limits, reduction switch and zero position inspection optoelectronic switch. If the assembly moves out of first limit, the motor will slow down; if it exceeds second limit, the motor will slow down until stop to avoid destructive impact to servo system. The zero position inspection optoelectronic switch determines the position of worktable when it stops.

The X worktable assembly is installed on the main unit platform, Y worktable assembly is installed on X worktable assembly. The worktable board is made of imported aluminium of high quality, which helps to achieve light weight. Y worktable assembly is equipped with turning plate. The turning plate serves to allow the PCB to rotate in $\pm 90^\circ \pm 180^\circ \pm 360^\circ$ to insert electronic component in different directions. As to turning plate, there is a round rotating plate in Y worktable, the round rotating plate is supported and located by four bearing that are installed horizontally. At each side of round plate, there is V-shape locating bracket, normally, the "tongue" of locating structure of work plate stretches out and touches V-shape bracket closely to fix round plate. The locating structure is composed of two single-acting cylinders, one elastic "tongue" and locating board. When turning plate needs to rotate, air cylinder stretches out, "tongue" retracts and breaks away from bracket. The round plate rotation is driven by turning plate motor, the turning plate motor is connected with one elastic round wheel assembly through timing belt. The round wheel assembly is equipped with one air cylinder, when the round plate needs to rotate, this air cylinder stretches out, the edge of round wheel and round plate touches with each other tightly, the rotation of motor drives the rotation of round plate.

3) Inserter and housing assembly

The inserter is made up with encoder, motor, gear rack, bearing, and timing belt, etc. The inserter assembly is installed on square steel tube with size of 100*150*6. It is equipped with accessories of high precision and stability, such as motor, gear rack, bearing, synchronizing wheel, and a set of camera, etc.

The motion of inserter is realized by Panasonic servo motor controlling material transfer and insertion.

Note: the insertion motion steps as follows: material transferring is done by double chains of high precision carrying component to inserter, then centering component by centering assembly which is of high accuracy, then the component is moved under the inserter by chain; at this time, insertion main shaft (H) gear shaft rotates after driven by servo motor, and brings gear rack to move downward as well as shear blade, then the

component lead is cut off, the former moves down also and clinches the two leads of component, the whole component is bent into splayed shape; the pusher continue to move downward, and pushed the bent component into PCB. Meanwhile, driven by clinch motor, the two clinch air cylinder stretch out, and bends the two leads of component that is inserted already, and cut off the excess lead, then the component is fixed on PCB. After that, housing moves down and back to original position rapidly, insertion main shaft will move up and back to original position quickly. These motions will be repeated until next command is given.

4) Jump Wire Assembly

This machine can move jumper(jump wire) to the bottom of insertion head for insertion directly without being sequenced by sequencer. Feed motor rotates and drags jumper (jump wire) from left to right, while the jumper is straightened and moved to the bottom of insertion head to be inserted (same motion as electronic component insertion).

5) Electricity and Air Control Device

Electricity and air control device supplies power and control signal for machine.

All the motion command of this machine is input and output by computer. The detection signal is input to computer through I/O board, and motion command signal in input to I/O board or servo through computer.

This machine will use 220V AC, 24V and 5V DC, and it is equipped with UPS AC power source. There is leakage circuit breaker at AC power source trunk, and protective at each branch circuit. DC is supplied by switch power. Grounding system must be standard and reliable.

Every AC servo motor is controlled by one servo. All servo parameters can be read or adjusted through servo screen, or can be read and adjusted in computer with dedicated software. The servo scree can show error code of servo system, which means, the servo is able to “diagnose by itself”.

Air supply of machine is input by air control assembly and supplied to relevant air cylinder by each electromagnetic valve.

6) Camera Assembly

Camera assembly is used to on-line program and correct PCB insertion coordination automatically.

Camera assembly is composed of camera and light source. Camera is installed at the left side of insertion head, and locked on a holder that can be jogged up and down. The camera lens can adjust focus and distance; the light source is installed under

camera lens and is used to aid shooting.

7) Servo Control

There are total 8 servo systems in this machine shown as below. The servo system ensures motion control with constant torque, wide-speed ration, high speed and high precision, which guarantees high performance of the machine. Since the motors use AC power, the machine is energy-saving.

Each servo motor is controlled by one servo. The signals of servo slow down, limit, and encoder are input to control computer; then servo is controlled by control card, station drive card and computer.

All servo parameters can be read or adjusted through servo screen, or can be read and adjusted in computer with dedicated software. The servo scree can show error code of servo system, which means, the servo is able to “diagnose by itself”.

Mature servo software and hardware technology ensures that error rate of servo system is almost zero.

Item	H shaft	C1 shaft	X shaft	Y shaft	C shaft	C2 shaft	B shaft	W shaft
Name	head	Sequencer chain	X shaft	Y shaft	span	centering	housing	jump wire
power	1000W	750W	400W	400W	400W	400W	400W	100W

8) Electric

This machine uses monophas power of 220V AC with frequency of 50HZ. Power consumption rate is 1600W.

This machine is equipped with UPS, which can keep the machine continue to work around 15 minutes and avoid waste of components waiting to be inserted when the plant has power outage.

Design of electric control circuit is very scientific, and material of electric component comes from famous brand with high quality.

Besides of 220V AC power, the machine also uses +24V DC and +5V DC through switch power.

9) Equipment / System Grounding

There is a grounding connecting wire on the machine for equipment/ system grounding. User is supposed to ground the machine properly to effectively control power obstruction and differential electric potential of large system.

Note: Please refer to international electric code and relevant local electric code to identify correct size and position of grounding connector. These grounding connectors

are additional (not substitution) to the grounding wire for signal cable and power cable. The grounding connector of power cable also needs to be grounded, which is usually processed through conduit of wiring system. The ground must be powerless, not only neutral, you can not select power cable conduit as the only grounding point. If possible, the system power board should also be grounded. No matter what kind of grounding system is applied, the earth impedance must be maintained within DC-10mHZ and lower than 10OHmS. The grounding system should be separated from power obstruction source to prevent the obstruction from being transferred to equipment/system through grounding system.

10) Adjust equipment leveling

After the machine is moved to target place, you can put down the machine foot and adjust the machine leveling by placing a leveling instrument on the machine. Proper machine leveling can minimize machine vibration and enable the machine to work more smoothly with less noise and longer life.

Steps to adjust machine leveling:

- a) Lift the machine in the air completely and move it to target place.
- b) First adjust the machine right & left leveling; since the machine gravity center is in the rear part, thus adjust the two rear feet.
- c) Then adjust the machine front and back leveling; you only need to adjust one front foot because three points finalize one surface.
- d) Revolve down the foot hanging and revolve a little further, and tighten the locating nuts on four feet.

Note: it will be rapid and efficient to adjust leveling by putting three feet on the ground.

11) File System Introduction

The D:\ disk in home directory contains following important file folders:

- 1) File folders S4000: the file used to keep application program S4000.exe.
- 2) File folders Installation: is to keep files that already registered for Southern Machinery AI equipment, it is temporary data file generated from registration.
- 3) File folders Southern Machinery data: is to keep parameters of equipment, component parameter, camera, original position test, statistic record, and factory default for relevant application program in Excel work sheet.
- 4) Equipment parameter: keep some parameters of AI equipment, such as insertion head excursion constant CX, insertion head excursion constant CY. Insertion head stroke constant HL, etc.
- 5) Component parameter: keep parameters of component specification, diameter, lead span for the equipment (the parameters can be added based on the type of

component to be inserted).

Warning: Deletion or manual modification of above files is forbidden, otherwise the application program will be damaged and can not run normally, which will result in mal-function of equipment or even equipment destruction..

12) Industrial Control Computer and Software Installation:

1) Open mainframe box, install image collection card and motion control card

Matters need attention: be careful about ESD protection.

Installation and set up of motion control card: (1) make sure that your computer system is stable (2) make sure the computer is registered by Southern Machinery (3) make sure there are at least three PCI slots on computer mainframe (4) first run the file: D:\install →Win2k_xp →PISO_DIO_Win2k_V241, then run REGIST2K in board card, next run REG2K, then shut down the computer, insert the control card PISO-C64 into PCI1 slot, insert two DMC1000 (motion control card) into PCI2 slot and PCI3 slot separately (5) open the computer, and copy Southern Machinery data and XG-2000E file folder into D disk, then install the safety dog into USB slot (6) after finish computer self-check and enter operating system, right click my computer attribute→hardware→equipment device managers, click the "+" of Leisai Controjjer (motion control card), and find DMC1000, right click attribute driver→update driver→search for the suitable driver for my equipment →next step →appoint one place→next step →browse (find D:\install\board card\DMC100) and open→sure→next step, the driver is installed automatically; the installation procedure of second motion control card is same, browse (find D:\install\board card\REGISTER) open →sure→next step, then the driver of the board card is installed automatically.

(7) Install P32-C32 motion control card, run PISO_DIO_Win2K_v241 in installWin2K and install. (8) Open and run S4000E.exe

2) Matters need attention: set up of computer mainframe BISO,

- **CPU configuration** →**Hyper Threading Technology [Disabled]**<close hyper-thread technology>**Onboard Devices Configuration** →**Onboard AC'97 Audio [Disabled]**<close mainframe intergrated soft soundcard>
- **Drive A/B**→**1.44M,3.5 in[None]**<close floppy driver start>
- **USB Cnfiguration** →**Legacy USB Support [Disabled]**< prohibit **USB** memory disk autostart. If not prohibited, **USB** memory disk will start computer, it is possible that the computer can not start or get infected by virus.>
- **Boot Settings Conftguration** →**Boot Num-Lock[off]**

3) Divide computer into three areas: C: 20G; D: 30G; E: 30G; and formatting them all as NTFS system; NTFS formatting is more stable and reliable than FAT32. (Note: take

80G hard disk as an example, equipment does not have any special requirement for hard disk size)

- 4) Install system software WINDOWS 2000+SP3/SP4
- 5) Install computer mainframe driver
- 6) Install computer display card driver
- 7) Install motion control card
- 8) Install safety dog (4000) driver
- 9) Install Database Driver
- 10) Install: WINRAR, five-stroke input method, Execl, etc. (not required by equipment, customer can install according to actual need)
- 11) Copy S4000E file folder
- 12) Copy Southern Machinery data file folder
- 13) File Backup
 - In order to avoid production data loss, we recommend you use clean USB memory disk without virus to copy Southern Machinery data file folder and file folder of camera as backup every two or three days.
 - If the machine shows “execl table incompatible” or “file format incorrect”, please conduct overall virus detection and destruction under safe mode, and install Office software again, then delete all files that have execl table.

13) Computer Setup

- 1) Display color: 32 bits true color
- 2) Screen resolution: 1024×768 pixel
- 3) Set Screen Protection as “Non”, and Power Management as “Always on”.
- 4) Virtual memory: initial size: 500MB, maximum size: 1000MB

Attention: install and run antivirus software casually, because when AI is working, it needs to access to hard disk file frequently, and antivirus program usually first check read-write file, which affecting the AI performance and system stability. If the computer is suspicious of virus, you can create and install antivirus software, after destroying virus, uninstall the antivirus software or stop running it.


Warning: if data exchange with outside is needed, please make sure that outside device (USB flash disk, CD, Floppy disk) does not contain virus!

14) Safety Check before Operation

- 1) Check if the power supply is appointed rated voltage.
- 2) Check if mainframe is connected to machine, if safety fuse is in good condition.
- 3) Check if the equipment is properly grounded.
- 4) Check if there are impurities in power control panel.
- 5) Whether conveyor belt derails during transportation.

- 6) Press emergency stop switch, push and pull X, Y Assembly, see if they can move flexibly.
- 7) Limit check, check if limit switch is dislocated.
- 8) Check if bearing, lead screw, rail, gear friction assemblies are in good condition.
- 9) Check if emergency switch can bounce.
- 10) Check if UPS or regulator can work normally.
- 11) Check if all the sockets in power control panel are connected properly.
- 12) Make sure all connecting cables are connected properly, no loose.
- 13) Check general electric switch is at OFF status.

3. Machine Assembly Motion Chart:



Automatic Axial Machine Working Scheme

Chapter 2 Installation

1. Tools come along with machine

- 1) One tool box;
- 2) A set of metric hex key spanner (9 pieces);
- 3) A set of open spanner (5.5-7 8-10 12-14 17-19 22-24) and a set of dedicated spanner;
- 4) A set of cross-shaped screwdriver and a set of slotted screwdriver;
- 5) sharp-nose pliers, diamond file, etc.

2. Install from “Part” to “Total”

Some parts of machine are broken down into pieces for the sake of packaging and transportation.

- 1) The sheetmetal door and front plate at both side of machine shell have been torn off, put the boards on the machine and lock the screw in relevant screw hole, and fit the boards to be aligned.
- 2) The warning light on machine shell has been torn off. First put wire through the installation screw hole of warning light, then turn metal tube into light installation screw hole and tighten the nut. At last, connect the wire one by one according to numbers.
- 3) Adjust equipment leveling

After the machine is moved to target place, you need to adjust machine leveling. Proper machine leveling can minimize machine vibration and enable the machine to work more smoothly with less noise and longer life. The leveling of machine means adjust the stretch length of the adjustable plate on the four machine feet.

Steps to adjust machine leveling:

- 1) Place a leveling instrument on the machine workbench.
- 2) First adjust the machine right & left leveling; since the machine gravity center is in the rear part, thus adjust the two rear feet.
- 3) Then adjust the machine front and back leveling; you only need to adjust one front foot because three points finalize one surface.
- 4) Revolve down the foot hanging and revolve a little further, and tighten the locating nuts on four feet.

Note: it will be rapid and efficient to adjust leveling by putting three feet on the ground.

3. Connect Power and Air Resource

Attention please: before connect power, first make sure machine overall power and air supply are cut off.

- 1) Connect the power connector that at left-rear side of mainframe to 220 V AC power, use national standard wire of $3(L+N+E)*2.5 \text{ mm}^2$. Grounding system must be standard.
- 2) Connect the input terminal of air control assembly that at the right-front side of machine with air pipe of $12*8.5$ to introduce air source.

Attention: please clean up the impurities in air pipe before supply air to machine.

Chapter 3 Operation

1. Safety Check before operation

Please you must pay attention: when machine is newly installed or in idle for long time, please do following safety check carefully before supply power and air to the machine and operate the machine.

- 1) Check if the power supply is appointed rated voltage
- 2) Check if power is connected to machine, if safety fuse is in good condition, and whether branch breaker is closed.
- 3) Check if the equipment is properly grounded.
- 4) Check if there are any irrelevant items left in power control panel and moveable part of machine.
- 5) Conveyor belt or timing belt derails during transportation.
- 6) Check the mechanisms that are of heavy load and running fast are connected well, such as lead screw, rail, insertion shaft.
- 7) Use hand to push and pull X, Y, H (insertion head), B(housing), C(span),C1(chain),C2 (centering), W(jump wire) Assembly, whether they can move smoothly.
- 8) Check if each dispenser is retreat back at safe location.
- 9) Check if limit detection and limit assembly are dislocated.
- 10) Check if emergency switch is pressed down, check whether overall air supply and power supply are at OFF status.
- 11) Check if all connectors and air pipes of computer and power control panel are connected properly.
- 12) Check if UPS contains enough power, otherwise you need to charge it at least for 4 hours.

2. Power on and off

1. Power on

Before you turn on the machine, please make sure there is no impurity inside the machine, no jam in rear station, and no impurity on the chain; When power on, please do not put your hand or other stuff into the machine. This machine is controlled by industrial automation computer, it takes some time for it to start and be ready.

Operation order:

- 1) Confirm the machine main power circuit breaker is ON.
- 2) Confirm the emergency switch is not pressed down, and whether each machine switch and power is connected.
- 3) Press the LCD power button on operation panel, and then press the

computer power button on operation panel to start the computer.

- 4) Turn on the air switch at the left side of machine, then the machine power is on, and then turns on emergency stop switch on operation panel, the servo power is on.
- 5) When computer is fully ready, click the icon **【my computer】** on desktop, then click D disk, click S4000 directory in D disk, then double click S4000 icon in S4000 directory, wait for several seconds and enter into S4000 production menu, click start button or press start button on operation panel, then machine reset starts.



2. Power Off

In order to avoid damage to computer hard disk, and ensure completion of current production program and data, when shut off the power, please you must follow steps as below to shut down the machine properly.


Turning ON/OFF the machine repeatedly will be one of the causes of equipment and UPS errors. Once the power is off, please at least wait for 20 seconds before you turn on the machine again.

Operation order:

- 1) As picture shown below: click operating system menu (file) to exit to program. Then production program at present will be saved automatically into D disk "Southern Machinery data" file folder with name of slast. When the machine is trun on again, the machine will autocall this program. If the machine is not shut off normally or has power outage suddently, then the present program will not be saved, as a result, when turn on the machine again, you have to call the program saved normally last time. **Normal shut down step as following:**
- 2) **Single-click file → exit → sure**




- 3) Click Win2000 (Start) → (shutdown), exit as normal procedure for Windows system shut down process.



Then switch off the general power of equipment, and turn UPS to Off status. If shutdown will last for more than 24 hours, please turn the equipment main power circuit breaker to OFF status.

3. Operation Interface Introduction, divided in 4 areas.



1. Control panel area: this area controls machine operation and production. (as picture above)

Explanation for buttons at control panel area:

Shift: It only shifts workbench, no feeding and insertion.

Idle spin: It moves workbench in order and idle insert, no feeding.

Insert: The sequencer chain and insertion chain run.

Single step: Except for “Start” button, in order to excute any function or open any file, you need to single click on it. During process of shift, and automatic insertion, if you click on it, shift will end and insertion will stop after every component. If you want to continue with automatic run, you must click on “automatic” again.

Automatic: Complete action in order based on program.

Single-cycle—continuous: It is a compound button. Normally, single-cycle means the machine stops after shift, idle spin or insert, and only after press start again, the machine starts to shift, idle spin or insert again. When you single click “Single-cycle”, the button becomes “Continuous”.

Feed jump wire: Click Jump Wire Assembly once, feed jump wire once.

Zero: Turn workbench, turn plate, H shaft, etc, to zero position. This is a must to zero all the mechanism before shift and insert for the first time.

Insertion head: It is head motor switch, green means effective, yellow means ineffective, at this time you can turn the head part manually.

Centering: C2 Assembly centers the material on the chain once.


Air Supply: Turn on or off all air supply of machine.

Rectify: Conduct visual rectify for coordinates in all programs, “Non” means no visual rectify, “√” means to do automatically rectify for the machine.


Start: Start the machine to conduct certain movement, and send out command of “Start”.

Stop: Stop all the motions.

Missing part inspection: Inspect missing part when inserting. Start missing part inspection function by putting “√” in the square grid; if no “√”, then no inspection for missing part.




2. Video Attribute Area: This area shows the image of PCB taken by camera.



3. Run-time information area: This area shows production status and production information.

First, there is color indicating production status, green means normal, yellow means missing part, red means wrong part. Picture below shows the program names and program quantity of present production.



- 1) Program name: It shows the name of program that is going to run or has already run; it changes as you “run” different programs.
 - 2) Quantity: It shows the total line quantities of the programs are running.(including 0S turn plate line)
 - 3) Set quantity: Set the number of PCB to be inserted. When the quantity set is met, the machine will stop automatically. Normally, the quantity is set as 2 automatically. If you single click it, a dialogue box will pop out asking you “Do you want to set up target quantity?” If your answer is “Yes”, you can put the new target quantity directly. If the answer is “No”, click on “Cancel”, and return to previous interface.
 - 4) Quantity completed: every time when insertion has done for one PCB, the production record will be updated automatically to show how many PCBs have been inserted.
 - 5) Dispense inspection: it means inspect for missing part when transferring components, if there is no component on corresponding chain, the machine will stop, and show yellow.
 - 6) Insertion inspection: conduction inspection for missing part when inserting. Start missing part inspection function by putting “√” in the square grid; if no “√”, then no inspection for missing part.
 - 7) Real time speed: actual speed of insertion.
4. Program edit area (such as picture): This area is to create or revise coordinate program where the program is open to manual edit. To enter program edit area, first click “single step” at control panel, then click the “edit” button at program edit area.



Edit: After click “single step” and “edit”, this button become yellow, and the character becomes “exit edit” and the button box frame becomes dotted line, then you can edit the program. After you finish editing, click this button to exit. If you do not single click “Confirm” after editing, the dialogue box will pop up asking “The edit is not confirmed! Do you want to confirm?” if you select “Yes”, then the change will be saved, if “No”, the change is not saved.

(Note:for function column, only I1.I2.I3.I4 can enter into or exit from edit)

Visual correction: single step + edit, then click Visual correction, it turns to yellow, and image attribute area will show the image of PCB taken by camera.

Exit Visual correction: exit visual correction.

Excursion: when edit X and Y for the third row of program, this button will turn green, after you finish revising, and single click it before you exit from revision, then all the X, Y coordinates in all rows of the program will excuse automatically based on the revision done in third row. If you exit from revision after revising, and single click it, then the “excursion” is null. (Note: only under the condition of OS — the row is insertion row, there will be excursion.)

Enter: single click it, then all the revision done will be saved.

Up arrow: under the condition of “edit”, click it, will move to the program in last row.

(Note: if the last row and next row is T1 or T2, then clicking on it is not allowed)

Down arrow: under the condition of “edit”, click it, will move to the program in next row.

Former: pusher tip goed down and bends component into U shape, but not insert.

Push: pusher tip moves down and push out component.

Reposition: pusher tip returns to original position.

Housing up: housing goes up..

Housing down: housing goes down and returns to original position.

Clinch clinch: clinch reaches out.

Clinch retract: clinch retracts to original position.

EXIT: After adjusting coordinate, if you want to repeal and you haven’t enter the adjustment, you can click it to return the coordinate to the previous value before adjustment.

Arrow button: when doing visual correcting, use arrow button to adjust coordinate.

The direction of arrow indicated the movement direction of insertion head (namely the movement direction of workbench).

Number selection: the numbers 2, 10, 100, and 1000 means the movement distance of coordinate, you can select the movement distance by using “arrow button”.

The ration is 100=1 mm.

C+: increase the width of C shaft.

C-: reduce the width of C shaft.


Rectify: choose “rectify current row” in control panel area, if you click it, the current row will be automatically rectified.

5. Explanation on Toolbar



1) File

single click: single step + file = open program, save program, save image, and exit(text format explanation: click on『single step』, then click on『file』, then the fuction buttons like 『open program, save program, save image, exit』 will pop out, following same format are applicable to the same analogy)



Open program: open existing production program.


Save program: save production program to the appointed file folder.

Save image: save vedio image to the file folder at the same location as program.

Exit: exit from production menu, return to previous oprating system.

2) Quantity

Single click on quantity, function buttons like quantity set up, revise, end submenu will pop up. After ending submenu, you can revise the relevant quantity.



Set up: set up the quantity needed for production.


Revise: revise the production quantity set as above. (Quantity needs to be smaller

than the set up)


End: end after the set up production quantity is achieved. (stop after all the componnets on the chain are inserted)

3) Set up

single click set up button, the dropdown menu,including equipment parameter, component parameter, and revise password. (shown as picture below)



(1) Equipment parameter (as picture):



All machine parameters adjustment is done in equipment parameter, including camera position CX and CY, H deep insertion position HL value, feed compensation, turn table compensation R1 and R2, housing travel distance BL value, clinch time TMC value, machine stop position X(Y), camera brightness adjustment, etc. After you revise the parameter, you need to click application, save then click return.

Camera position CX: the coordinate for the center of a pair of former at X shaft based on camera center as zero position.

Camera position CY: the coordinate for the center of a pair of former at Y shaft based on camera center as zero position.

H deep insertion compensation HL: compensation for insertion depth of insertion head.

Feed compensation: compensation for jump wire length.

Centering compensation: compensation for travel distance of centering assembly.

Forward turn table compensation R1: when turn table rotates forward, compensation for the time to allow motor continues to rotate.

Reverse turn table compensation R2: when turn table rotates in reverse, compensation for the time to allow motor continues to rotate.

Clinch time TMC: working time of clinch motor.

Machine stop position X: after workbench zeros, the actual position of X shaft is bigger than zero position, usually is 22860.

Machine stop position Y: after workbench zeros, the actual position of Y shaft is bigger than zero position, usually is 22860.

Centering compensation: backup item.

Housing travel distance BL: compensation of rising height of housing.

Chain speed: adjust the speed of carrier chain and sequencer chain (C1).

Speed adjustment: adjust the overall insertion speed.

Station quantity ST: show total quantity of machine stations.

Feed compensation HW2: compensation for error value of feed wheel.

Camera brightness adjustment: adjust the brightness of picture taken by camera.

Application: apply default values that are saved.


Read: single click read, the default value will show up.

Save: save the parameters that get revised.

Return: exit from current page, return to previous operating system interface.

(2) Component parameter: component parameter is to classify all the components in insertion program according to certain criterion, and describe features of component. (If you want to add the component type, you can add it in component bank at D disk Southern Machinery data)

When you single click it, the following parameters will show up. (See picture):



Serial number: serial number of component.

Type: type of component, based on watt level.

Diameter: diameter of component body.

Lead diameter: diameter of component lead.

Component length: length of component body.

H speed: speed of insertion shaft H.

XYZ speed: move speed of workbench and C shaft.

: single click it, the parameter of component with last “serial number” will show up.

: single click it, the parameter of component with next “serial number” will show up.

Read: single click read, the default value will show up.

Save: save the parameters that get revised.

Return: exit from current page, return to previous operating system interface.


(3) Revise password:

Setting up equipment parameter password can prevent random change, if there is no password, revise can not be done. Before the machine leave the factory, the password for equipment parameter is set usually as 0000.

4) Diagnose

It is to diagnose the current status of input signal and output signal as well as the status of servo system movement.

Single step + diagnose= common input signal, common output signal, dedicated input signal, station driver, servo system, turn table, etc.



(1) Common input signal: it shows current signal status of input channels, such as each photoelectronics, magnetic induction, safety switch, etc (input to computer through machine). The status described down is the machine standby status, when the machine works, the status changes between “high” and “low”, “high” and “low” are short terms of high level and low level. This control software is effective for low level.

Input Signal			
No.	Mark	Name	Status
1	IN1	Emergency stop	high
2	IN2	Head safety	Low
3	IN3	Guardrail safety	Low
4	IN4	Head switch	high
5	IN5	Insert inspection 1	high
6	IN6	Insert inspection 2	high
7	IN7	Start	high
8	IN8	Stop	high
9	IN9	Sequencer inspection	high
10	IN10	Spare	high
11	IN11	Turntable at place	Low
12	IN12	Turntable at zero	Low
13	IN13	Jump wire insert make up	high
14	IN14	Spare	high
15	IN15	Spare	high
16	IN16	Spare	high

Emergency stop switch: when press down the emergency stop switch on the shell, the status will change from high to low, all power of servo motor will be shut off.

Head safety: this in optoelectronic switch detection signal is used to prevent the H shaft from going down to unsafe position.

Guardrail safety: this switch is set up to protect the moving door of machine. When you open the door, if you do not turn the safety switch manually, the low level will be released and all the working machines will stop.

Head switch: it is the enable control switch signal for servo of H shaft.

Insertion inspection: inspect the insertion status of two component leads. L and R represent the signal of left and right clinch. When inserting, if the component is not inserted into the hole or the clinch does not touch the component lead, the machine will stop or alarm. The normal status is high, otherwise it is low. The signal is from clinch, and the theory is that when the process is normal, the clinch and ground will form loop.

Start: when press down the start switch at machine shell, its status will change

from high to low, the vise versa.

Stop: when press down the stop switch at machine shell, its status will change from high to low, the vise versa.

Sequencing inspection: when carrying the component while inserting, if there is no component on the chain, the machine will stop, its status will change from high to low, the vise versa.

Spare: the singlar interface not used.

Turn table at place: when “at place” magnet on turn table approaches the “at place” magneto sensitive component of turn table sensor, turn table sensor will send out this singlar. This determines the turn table whether stops or continues to rotate.

Turn table zero position: when “zero position” magnet on turn table approaches the “zero position” magneto sensitive component of turn table sensor, turn table sensor will send out this singlar. This determines the turn table whether returns back to zero position.

(2) Special input singlar: It is the singlar status of current output (input to computer) by the optoelectronic switches on each shaft.

Special Input Signal			
No.	Mark	Name	Status
1	+ELX	X shaft positive limit	high
2	-ELX	X shaft negative limit	high
3	+SDX	X shaft positive slow down	high
4	-SDX	X shaft negative slow down	high
5	ORGX	X shaft original point	Low
6	+ELY	Y shaft positive limit	high
7	-ELY	Y shaft negative limit	high
8	+SDY	Y shaft positive slow down	high
9	-SDY	Y shaft negative slow down	high
10	ORGY	Y shaft original point	Low
11	+ELC	C shaft positive limit	high
12	-ELC	C shaft negative limit	high
13	ORGC	C shaft original point	Low
14	+ELH	H shaft positive limit	high
15	-ELH	H shaft negative limit	high
16	ORGH	H shaft original point	Low
17	ORGB	B shaft original point	Low
18	ORGChr	Chr shaft original point	Low

X, Y shaft: workbench shaft.

C shaft: the width shaft for cutting, forming and clinch.

H shaft: main insertion shaft.

C1 shaft and C2 shaft: insertion chain, sequencer chain shaft and centering.

Positive and negative limit: they are short terms for the optoelectronic switch signals of the maximum position at positive and negative direction of each shaft.

Positive and negative slow down: it is to send out signal of “start slow down”. They are installed in front of optoelectronic switch of positive and negative limit. When inspection sensor blocks the light emitter of optoelectronic switch, servo motor will start to slow down gradually and stop until it reaches the limit.

Original point: is to set up the detection signal of machine “zero point”.

—You can put a piece of paper between the light emitter and light receiver of each optoelectronic switch, normally the signal will change from low to high as the paper goes in and out. Otherwise the optoelectronic switches are broken or circuits are abnormal.


(3) Common output signal. It shows the status of each motion signal sent by computer. If you single click each button under “status”, movement status will change between “high” and “low”. “High”, means there is no movement; “low”, means there is movement.

Output Signal			
No.	Mark	Name	Status
1	OUT1	Flashlight1	high
2	OUT2	Spare	high
3	OUT3	Green light	Low
4	OUT4	Yellow light	high
5	OUT5	Red light	high
6	OUT6	Clinch	high
7	OUT7	Turntable lock open	high
8	OUT8	Turntable pinch roller	high
9	OUT9	clockwise	high
10	OUT10	counterclockwise	high
11	OUT11	Lead leg inhaler	high
12	OUT12	Air supply	Low
13	OUT13	Insertion head	Low
14	OUT14	Spare	Low
15	OUT17	Center up &down	high
16	OUT18	Center RH&LH	high


- Flashlight: it is the light source of camera. This machine only needs one flashlight.
- Spare: the signal interface not used.
- Green, yellow, red light: the warning lights on the shell.
- Clinch: control signal of electromagnetic valve for air cylinder of clinch.
- Turn table lock: the electromagnetic valve for air cylinder on turn table lock assembly.
- Turn table clamping roller: the electromagnetic valve for air cylinder on turn table clamping roller assembly.
- Clockwise: relay signal that controls turn table rotate in clockwise.
- Counterclockwise: relay signal that controls turn table rotate in counterclockwise.
- Lead leg inhaler: signal of lead leg inhalation, not useful temporarily.
- Air supply: signal for general air supply.
- Insertion head: signal for head motor.

(4) Servo system (dedicated diagnose area for each servo shaft).

Input value within limit (blue number) in the input boxes of “travel distance” and “speed” of relevant shaft, when you single click the direction arrow (or direction button) once, the shaft will move once according to the value input and direction chosen, until the shaft reaches the limit and get protected (except for W shaft). Among them, W shaft is shaft for feeding jump wire, and it only moves in one direction. B shaft is housing motor, C2 is centering, C1 shaft is insertion and sequencer chain, and other shafts have been introduced before.



(5) Turn table: It is the worktable that turns.



Clockwise: worktable rotates in clockwise.

Counterclockwise: worktable rotates in counterclockwise.

Return: exit from present operation interface and return to previous operation interface.

6) Station driver (shown as picture below):

Press “-” button, station position will move one step forward.


You can put the target station in number input area directly.

Press “+” button, station position will move one step backward.

Press driver button, program start to execute the command input above, and test the station.




7) Statistics: current production program information and operation information. If you select appropriate information, the selected information window will pop out and conduct statistics.



(1) Program information: show information of current production program. For example:

Insert Sequence X2G090819									
N	Loc	X	Y	C	D	PartNo	PartTp	Feeder	Fun
1	OS	22500	22500	1000	100	999	JW	0	OS
2	T1	0	0	1000	100	999	JW	0	T1
3	OS	-1768	5780	756	100	999	JW	0	OS
4	VD561	14319	23820	968	100	999	JW	0	I4
5	W553	14314	23061	1471	100	999	JW	0	I4
6	R4	14321	22323	1463	100	999	JW	0	I4
7	R5	14039	21624	1245	100	999	JW	0	I4
8	R6	14006	21327	1175	100	999	JW	0	I4
9	R7	13902	20155	965	100	999	1/6W	1	I1
10	R8	13657	18088	980	100	999	1/6W	6	I1
11	R9	12008	19998	985	100	999	1/6W	1	I1
12	R10	9871	18453	1466	100	999	1/6W	6	I1
13	R11	7439	19284	976	100	999	1/6W	1	I1
14	R12	6825	18523	975	100	999	1/6W	6	I1
15	R13	6473	18290	1479	100	999	JW	0	I4
16	R14	5520	17572	1472	100	999	JW	0	I4
17	R15	6656	17333	1476	100	999	JW	0	I4
18	R16	6659	16969	1481	100	999	JW	0	I4
19	R17	5163	15227	740	100	999	1/6W	1	I1
20	R18	5158	14965	732	100	999	1/6W	6	I1
21	R19	5182	14696	729	100	999	1/6W	1	I1
22	R20	5176	14439	724	100	999	1/6W	6	I1
23	J3	7759	14769	725	100	999	1/6W	1	I1
24	J4	7763	15017	722	100	999	1/6W	6	I1
25	J5	7769	15276	717	100	999	1/6W	1	I1

(2) Operation information: information including yield, standby time, insertion time, etc. You can save the information automatically into D disk "Southern Machinery data" file folder, "statistic record" file folder directory, the file is named by the time when it gets saved, when you click drop-down menu and exit from production menu, the information will also be saved here automatically.



Attention:

Save: press save button, then the information will be saved in D disk “statistic record”.

Zero clearing: press the zero clearing button, all operation information will be 0.

■Operation information: information including yield, standby time, insertion time, etc.You can save the information automatically into D disk “Southern Machinery data” file folder, “statistic record” file folder directory, the file is named by the time when it gets saved, when you click drop-down menu and exit from production menu, the information will also be saved here automatically.

6. Panel button explanation.



- 1) Start: same function as the “start” on operation interface.
- 2) Stop: same function as the “stop” on operation interface.
- 3) Jump wire supplement: press the button, the jump wire missing will be

supplemented at the same position.

- 4) Emergency stop: stop button under emergency, press the button, machine will shut off power of all servo motors.
- 5) USB: USB input\ output interface.

4. Operation procedure

1. Turn on machine power: switch on the main power circuit breaker at the left side of machine mainframe.
2. Turn on computer: “computer” button. The computer is installed right under the operation panel, after the machine cover is open, the computer will be seen.
3. Supply air to machine: click “air supply” button on the operation control panel, the housing will get air supply.
4. Turn on emergency stop switch: turn on the emergency stop switch on shell in clockwise.(the button will go up)
5. Conduct diagnose: check if signal status is normal, check if there is motion, check if machine control system is normal. Please see operation in Chapter 3, explanation of “diagnose” of each function “button” on operation interface.
6. Programing: Please see operation in Chapter 3, explanation of “program editing” of each function “button” on operation interface, as well as “program editing” in Chapter 4.
7. Access program: single click “file” on interface, single click “read program”, then single click the program name that you want to execute;set up “target quantity”.
8. Execute “visual correction” first then “idle spin”: “Visual correction”, please see explanation of each function “button”, “program editing” on operation interface. The purpose of executing this operation is to check if the coordinates in the program are correct, and also check if X\Y workbench moves within safe range, otherwise, the equipment will be damaged when conducting “Idle spin”. “Idle spin”, please see explanation of each function “button”, “Idle spin” on operation interface. The purpose of executing this operation is to check if insertion shafts can move normally, and also “warm up” each working assembly.
9. Insertion, insertion chain and sequencer chain work.
 - 1) First do: single step+ insertion, check the result of component insertion. If the insertion result is bad, please see Chapter 5, Adjust and Maintenance, “machine, computer parameter adjustment”.
 - 2) After finish insertion of one board, check insertion result, see if component position is correct, is there any miss, otherwise add program.....
 - 3) Conduct continue + insertion

10. Shut down the machine

- 1) Exit from operation system: Please see operation in Chapter 3, explanation of “exit from program” at operation interface for each function “button”.
- 2) Turn off computer: Please see operation in Chapter 3, explanation of “shut off computer” at operation interface for each function “button”.
- 3) Emergency stop: press down the emergency stop button on machine shell. ©
- 4) Switch off main power: switch off the main power circuit breaker at right side.


Warning: operating and maintaining this quipment by more than two persons is strictly prohibited, when maintaining the machine, please you must press down the emergency stop button on panel or shut off the power.

Chapter 4 Program Editting

Before inserting component to PCB, you must input a specific insertion program to computer. This program shows clearly: insertion sequency----1,2 ,3.....;The position of first component on the machine workbench ---X, Y coordinate value, namely OS position; the absolute coordinate(X, Y) value for the hole position of each component;and lead span value (C) of component, etc. This process of creating program, we call it as “program editting”.

1. Program Introduction

- 1) This equipment use Execl to edit program, and use metric absolute coordinate, then multiply by 100, and you can inreoduce the program of universal machine, DYNA machine, and masterplate, and edit it into the program applicable to this equipment. The picture below shows an example of program for a big board (wider than 20cm):



	A	B	C	D	E	F	G	H	I	J	K
1		PCB-6789C									
2	N	Loc	X	Y	C	Holdia	PartNo	PartTp	Feeder	Fun	
3	1	OS	23000	23000	1000	100	70	JW	0	OS	
4	2	T1	0	0	1000	100	70	JW	0	T1	
5	3	OS	493	7970	1000	100	70	JW	0	OS	
6	4	R1	8000	27300	1240	100	70	1/2W	1	I1	
7	5	JW	8020	26420	1000	100	70	JW	0	I4	
8	6	D2	8010	26120	1000	100	70	D4007	4	I1	
9	7	R7	8020	25800	1000	100	70	1/8W	6	I1	
10	8	OS	23000	23000	1000	100	70	JW	0	OS	
11	9	T2	0	0	1000	100	70	JW	0	T2	
12	10	OS	493	3457	1000	100	70	JW	0	OS	
13	11	R3	6006	2578	1240	100	70	1/2W	8	I1	
14	12	JW	7000	3532	1120	100	70	JW	0	I4	
15	13	D4	456	34672	800	100	70	D4007	7	I1	
16	14	R5	6893	345	1200	100	70	1/8W	9	I1	
17	15	E	1000	1000	1500	100	70	0	0	E	
18											
19											
20											
21											
22											
23											

2) All the English letters for function code in above program sheet must be capital.

3) All the dimension value is actual metric mm multiply by 100.

4) Explanation of program content shown as below:

File name: first row and first column of program, you can name it at will.

Program name: first row and second column of program, you can name it at will, but need to make it clear that it is program for which kind of PCB.

N: second row and first column of program, serial number column. The sequency of machine executing programs (also the sequency of insertion).

L: second row and second column of program, position serial number of insertion point on PCB board, better to be completely same as the serial number on PCB board.

X: second row and third column of program, X coordinate column.

Y: second row and fourth column of program, Y coordinate column.

C: second row and fifth column of program, C coordinate column, namely the span of component holes.

H: second row and sixth column of program, diameter of PCB insertion point.

PartNo: second row and seventh column of program, serial number of component inserted.

PartTp: eighth column of program, the parameter colume tells machine that what is

being inserted, component or jump wire component, it also controls the insertion depth of H shaft.

Feeder: second row and ninth column of program, station set up, feed material at which station.

Fun: insertion function column, code meaning shown as below ——

T1. command the workbench to rotate 90°in clockwise.

T2. command the workbench to rotate 90°in counterclockwise.

OS. Offset row of program, namely original point (OFFSERT) , this row is nominal row only, does not insert.

It is mandatory row; the next row right after it is the adjusting row for the coordinate.

I1. Insertion row, and conduct component missing inspection.

I2. Insertion row, but does not conduct component missing inspection.

I3. Norminal insertion row, it is error inspection row to detect off-standard insertion; this row executes insertion and inspection. When the PCB is not changed, or sequencer order error occurs or sequencer goes ahead, insertion will stop, this row is optional. It is set as the previous row of first insertion row with same coordinate as first insertion row.

I4. Jump wire insertion row, and execute inspection.

I5. Jump wire insertion row, and does not execute inspection.

E. Program end row.

2. Program editing procedure

1) Prepare tools: one digital caliper, two oil pens of different color, a sheet to create program.

2) First, based on BOM requirement, use oil pen to mark the component hole to be inserted and jump wire hole, use different color to mark the 0°and 90°, because when insert component at 90°,turn table needs to rotate 90°.


3) Connect the marks with a line, based on the connect order, the insertion sequency will be defined. Connection principle: first, the line should be effective and shortest, that is to say, try to avoid idle travel of machine when inserting, it helps to enhance insertion speed and production efficiency;second, 0° and 90° need to be linked in two separate lines, because when insert component at 90°,turn table needs to rotate 90°.

4) After drawing insertion sequency, use caliper to measure the coordinate data, the unit of data is mm. Before measuring the data, need to first confirm the two insertion locating holes on PCB board. Take clockwise continuous turn table insertion as an


example, when machine zeros, the round plate rotates 90° and turns into 0° insertion status, after rotating the two locating holes on PCB board will be at left side of board, one up and one down, when we measure the coordinate data, we can use the left-bottom corner of PCB as O point (namely original point), the bottom edge of PCB can be considered as Y shaft of axis, the left side of PCB can be considered as X shaft of axis, thus, measure from left to right, the result is X coordinate data, measure from bottom to top, the result is Y coordinate data; when measuring X coordinate data, use the fixed tip of caliper to clip on left side of board, and use movable tip to clip on the right side of the insertion hole, the data shown on caliper is X coordinate data, need to keep two decimal places. When measuring Y coordinate data, use the fixed tip of caliper to clip on bottom of board, and use movable tip to clip on top of the insertion hole, the data shown on caliper is Y coordinate data, need to keep two decimal places as well. The distance between the centers of two holes on insertion component is span, namely C in Southern Machinery data. After measuring all coordinates at the 0° surface, then measure the coordinate at 90° surface. The picture below is the placement status of PCB board when measuring coordinate at the 0° surface:

5) During normal production process, after inserting at the 0° surface, machine round plate will rotate 90° again, at this time, the two component locating holes are at the top of PCB, one left and one right. When we measure the coordinate data at 90° , we can still use the left-bottom corner of PCB as O point original point; when use caliper to measure from the left side of board to the right side, the result is X coordinate data; when use caliper to measure from the bottom of the board to the top, the data shown on caliper is Y coordinate data. The distance between the centers of two holes on insertion component is span. The picture below is the placement status of PCB board when measuring coordinate at the 0° and 90° :

S4000




6) After measuring coordinate data, create a EXECL worksheet in the file folder of D Disk “Southern Machinery data”, put down file name, and key in all the coordinate data into worksheet, and multiply the actual data with 100, and create the production program needed by Southern Machinery machine, when PCB is narrower than 20CM, the program shown as below: (following is the program of turn table rotates in clockwise, and insert continuously)



File Name	N	Loc	X	Y	C	HoldDia	PartNo	PartTp	Feeder	Fun
PCB-6789C	1	OS	23000	23000	1000	100	70	JW	0	OS
	2	T1	0	0	1000	100	70	JW	0	T1
	3	OS	493	7970	1000	100	70	JW	0	OS
	4	R1	8000	27300	1240	100	70	1/2W	1	I1
	5	JW	8020	26420	1000	100	70	JW	0	I4
	6	D2	8010	26120	1000	100	70	D4007	4	I1
	7	R7	8020	25800	1000	100	70	1/8W	6	I1
	8	OS	23000	23000	1000	100	70	JW	0	OS
	9	T1	0	0	1000	100	70	JW	0	T1
	10	OS	493	38570	1000	100	70	JW	0	OS
	11	R3	6006	2578	1240	100	70	1/2W	8	I1
	12	JW	7000	3532	1120	100	70	JW	0	I4
	13	D4	456	34672	800	100	70	D4007	7	I1
	14	R5	6893	345	1200	100	70	1/8W	9	I1
	15	OS	23000	23000	1000	100	70	JW	0	OS
	16	T1	0	0	1000	100	70	JW	0	T1
	17	OS	493	7970	1000	100	70	JW	0	OS
	18	R1	8000	27300	1240	100	70	1/2W	1	I1
	19	JW	8020	26420	1000	100	70	JW	0	I4
	20	D2	8010	26120	1000	100	70	D4007	4	I1
	21	R7	8020	25800	1000	100	70	1/8W	6	I1
	22	OS	23000	23000	1000	100	70	JW	0	OS
	23	T1	0	0	1000	100	70	JW	0	T1
	24	OS	493	38570	1000	100	70	JW	0	OS
	25	R3	6006	2578	1240	100	70	1/2W	8	I1
	26	JW	7000	3532	1120	100	70	JW	0	I4
	27	D4	456	34672	800	100	70	D4007	7	I1
	28	R5	6893	345	1200	100	70	1/8W	9	I1
	29	OS	23000	23000	1000	100	70	JW	0	OS
	30	E	1000	1000	1500	100	70	0	0	E

7) Following is the program of turn table does not rotate, only insert in one direction:



File name	N	Loc	X	Y	C	HoldDia	PartNo	PartTp	Feeder	Fun
PCB-6789C	1	OS	1000	1500	1000	100	70	JW	0	OS
	4	R1	8000	27300	1240	100	70	1/2W	1	I1
	5	JW	8020	26420	1000	100	70	JW	0	I4
	6	D2	8010	26120	1000	100	70	D4007	4	I1
	7	R7	8020	25800	1000	100	70	1/8W	6	I1
	11	R3	6006	2578	1240	100	70	1/2W	8	I1
	12	JW	7000	3532	1120	100	70	JW	0	I4
	13	D4	456	34672	800	100	70	D4007	7	I1
	14	R5	6893	345	1200	100	70	1/8W	9	I1
	15	E	1000	1000	1500	100	70	0	0	E

8) For the two program examples above, need to pay attention to following aspects:

- (1) In the program of turn table insertion, the OS coordinates of every two turn tables must be aligned, and the sum of X, Y of T1 or T2 plus X, Y of OS on turn table is approximately 23000.
 - (2) Coordinate of I3 and I1 must be aligned, because I3 is to execute wrong component inspection, so its coordinate must be aligned with that of I1.
 - (3) The HolDia in program must be filled, and all English letters need to be in capital.
 - (4) The sum of insertion row OS and coordinate value of X, Y for I1.I2.I3.I4.I5 must not be smaller than 0 or bigger than 45000, if it is not in this range, then it is out of limit of X, Y.
 - (5) When inputting the items, no “space” is allowed in between, otherwise the machine can not recognize.
 - (6) In machine parameters, component type must be included; otherwise the machine component can not be inserted in place or not clinched.
 - (7) If the component span is in the range of 500-2000(5mm-20mm), then the program must be in in first worksheet of EXECL file.
 - (8) In editing area, if in last row turn table, it is not allowed to click up arrow ↑, otherwise workbench will hit shear pin.
7. Turn on computer, enter insertion machine operation system and keep machine at normal status.
8. (Shortcut) single click “file”——“open”, select the newly created insertion program file
Click—open or double click, then the system opens the program file, machine will execute this program.
9. Start “zeros”.
10. Start “shift”——“single step”, move to the first insertion row under OS, namely offset row.
- Apply “program edit” and “Visual correction”, select the editing correction arrows up, down, left, right, and move unit distance 2, 10, 100, etc based on actual situation, and confirm the coordinate position of new offset row, when camera aligns with insertion hole, click offset confirmation button, and confirm a new offset coordinate.
- 11 Apply “program edit” and “Visual correction”, according to above method, confirm the coordinates of each insertion rows under offset row, but you need to click “confirmation” button after revising the coordinate of each row. After correcting all coordinates, click file — save, save new coordinate program file.
12. When creating a new program in Southern Machinery format, input component position in column L (component serial number);input the diameter of insertion point in column D;input the component type in column P(parameter), JW is jump wire, **W is the watt of component;input the function code of machine motion T1 or T2 in column F(i.e. turn table rotates 90° in clockwise or counterclockwise);OS is OFFSET position, it

determines the position of the first point on workbench; I1, I2,I;E is ending row, machine does not run this row.

13. After all machine insertion programs are corrected and saved, click panel shift — automatic— start, let the machine operates idle to see if the coordinate positions are correct. If all are correct, then you can start normal production next.

3. Verification program:

1)Set the PCB board in program stay at the original position.

2) After machine zeros, start single step + shift, shift to the second row of program (i.e.current row is insertion row), then click “edit” and “visual correction” in program edit area, see if the pount set and the cross picture of camera are concentric (standard insertion postion need to be concentric with cross picture),otherwise, use “edit” to correct.

3) Then click “exit from visual correction”, then click “Head” in the servo enable area of operation interface, turn off H shaft motor servo enable, hold H shaft adjust wheel and press down insertion head (need to have component clinched and to be inserted on the insertion head), see if the component lead can center the hole on PCB and be inserted properly, if can not center or can not insert, then you need to adjust the “equipment parameter” until the component can center and insert properly.

4) In “program edit” area, click down arrow, check if coordinates of each row are correct, if not right, thencorrect it.

5) At last (current row is insertion row) , click “exit from edit”, then click “file”→“save program”.

4. Introduce other program:

1) Use “bitmap coordinate editor” to intruduce program.

The program created by “bitmap coordinate editor” is in text format; need to transfer the text file into EXECL. Open the text file with “EXECL”, and save, copy the content you need into the standard program format of this machine, and optimize other content.

2) Use“Board mold” data to introduce

You can transfer the format of PCB board data ----PROTEL99 into the program format can be used on the machine. This data is in text format also, and usually in British system, so you need to transder it into metric, and transfer the format from text to EXCEL. We only take the component lead hole WID X and WID Y data, copy the content you need into the standard program format of this machine, and optimize other content.

Attention: our company has the PROTEL99 software, you can ask for it. In order to

keep the machine computer operate stably, it is not allowed to install this software to the machine computer and use.


3) You can introduce the program used in other machine into this machine for usage.

Chapter 5 Adjustment and Maintenance

1. Mechanical adjustment



1) Shear adjustment


There are six shears in the shear box, left and right shear S4000-01-04-047, S4000-01-04-052, left and right outer former S4000-01-04-048, S4000-01-04-051 and pusher tip S4000-01-04-49, S4000-01-04-050, left and right bottom former S4000-01-04-046, S4000-01-04-065. The installation standard of the shear: the clearance between top former and bottom former is 0.1mm, use your hand to feel the shear shking from left to right and no gap, and can move up and down smoothly; for bottom formers, the height of both sides must be the same, the S4000-01-04-069 and S4000-01-04-055 that fixing bottom formers can no have gap, otherwise it can not form properly. The picture below shows the break down pictures of each part of head assembly as well as relevant component serial number:




2) Adjust of shear box S4000-01-04-031 and left and right shear stand S4000-01-04-026, S4000-01-04-027.

(1) there is a standard shear block for adjustment, the detailed adjust steps: first put the block into S4000-01-04-031, make it fits with blade guiding slots of S4000-01-04-026 and S4000-01-04-027, install S4000-01-04-060 and S4000-01-04-061 and lock the screw, then install the connecting pieces bottom U shaft lead screw left and right S4000-01-04-024., S4000-01-04-025, and the connecting pieces is to connect left and right spinning lead screws and S4000-01-04-026, S4000-01-04-027. The installation standard: after all connecting pieces are installed firmly, use hand to push the block up and down, you can feel the block can slide up and down in the shear box smoothly.





(2) After the core parts of S4000-01-04-026 and S4000-01-04-027 are installed, you can adjust the left bottom former and right bottom former. Adjust method shown as below:




After install and adjust above assembly, you can hang it onto head aluminium block.

3) Adjustment of component centering assembly

(1).component centering assembly is to conduct centering of component center and insertion center in carrier clip before the component is inserted into the PCB board. Work theory—when air cylinder moves from farthest dwell point to nearest dwell point, left and right centering arms will move backwards to component, while the left and right

centering air cylinders decline gradually, V shape slot of left and right centering arms will move close towards center; with the clamp force of V shape slot of left and right centering arms, component is centered with insertion center by carrier clip through moving left and right horizontally; then air cylinder returns back to original position, left and right centering arms exit and return to original reposition. **Break down picture of centering assembly as below:**




Shown as above picture: 1. to adjust the centering clip to center left and right 3. it is up and down air cylinder 2. to adjust the downward depth of centering clip 10. it is left and right air cylinder, 6.to adjust the centering clip and component not aligned in Y direction.

4) Zero position adjustment

(1) Head optoelectronic switch adjustment

After original point optoelectric inspection block is settled down, open the diagnose in menu, use hand to rotate H shaft, and check the signal change of H shaft in dedicated input signal. There are three optoelectric inspection switches on H shaft, shown in picture below, they are: H shaft original point, H shaft positive limit, head safety, H shaft negative limit. The movement sequency is: when H shaft goes up, it will first meet head safety, H shaft original point, H shaft positive limit;rotate head in reverse direction, when insert down it meets with H shaft negative limit.




Adjustment method of H shaft optoelectronic switch as below:

- a. To adjust the H shaft positive limit optoelectronic switch, rotate H shaft manually from bottom to the highest top, then move down by 1mm, move positive limit optoelectronic switch inspection piece from bottom to top, and tighten the screw of inspection piece immediately when it is triggered.
- b. To adjust H shaft original point optoelectronic switch, rotate H shaft manually from bottom to the highest top, then move down by 2mm, move original point optoelectronic switch inspection piece from bottom to top, and tighten the screw of inspection piece immediately when it is triggered.
- c. To adjust the H shaft negative limit optoelectronic switch, with the premise of normal distance between up former and PCB board, push the pusher tip farther than former by 1.5mm, adjust H shaft negative limit optoelectronic switch from bottom to top, and tighten the screw immediately when it is triggered.


If the sequency is recerse, H shaft will not return to original point position, it will move in reverse direction. Turn on H shaft power switch, and let H shaft retun to original position automatically, and see if the position adjustment can meet requirement, if not, then adjust again until the result is OK.

(2) Adjustment of C shaft



- (1) Loosen the set screw of shaft housing.
- (2) Loosen anchor ear of synchronizing wheel, and adjust the axial center of each synchronizing wheel aligned to a straight line.
- (3) Move motor stand back and forth to tighten or loosen the timing belt for shearing and clinch, to meet stretching force requirement.
- (4) Loosen set screw of anvil C shaft stand, and move the stand up and down to tighten or loosen the timing belt for shearing and clinch, to meet stretching force requirement.
- (5) Tighten the set screw of shaft housing.

(3) Adjustment steps of C shaft and zero point limit switch:



- (1) Shut off the power at the front of servo motors of C shaft and H shaft.
- (2) Use manual joystick to low down the insertion head down position.
- (3) Rotate the insertion head driven wheel based on requirement, set the distance

between up formers as 20mm+0.25mm.

- (4) Loosen the set screw of positive limit optoelectronic switch inspection piece.
- (5) Turn the inspection from bottom to top until the C shaft positive limit switch is triggered.
- (6) Tighten the set screw of inspection piece.
- (7) Loosen the set screw of negative limit optoelectronic switch inspection piece, set the distance between up formers as 5mm-0.25mm
- (8) Rotate the inspection piece from inward to outward, until the C shaft negative limit switch is triggered, tighten the set screw of inspection piece.
- (9) Loosen the set screw of C zero position optoelectronic inspection piece, set the distance between up formers as 15.4mm
- (10) Rotate the inspection piece from bottom to top until C shaft zero position optoelectronic switch is triggered.
- (11) Tighten the set screw on zero position optoelectronic switch inspection piece.

5) Adjustment of each motor timing belt

There are total six timing belt in the equipment transmission system, timing belt should be tight moderately. When the timing belt is too tight, they will be worn out easily, and affecting the equipment precision and efficiency. For example, if the clinch driver is too tight, the relevant bar will be bent slightly; if the transmission belt is too loose, then the issues of center span incorrect and clinch length change will occur together. The adjustment method of timing belt for each transmission part as below:

(1) Insertion head driver timing belt

The tensile force of this timing belt will change the set of H shaft limit switch, and will also affect the insertion tightness. If you want to check whether the tensile force is correct, you can put pressure on the driver belt span—0.45kg(1 pound), the pressure will pull down the driver belt radian by 10mm, if still need to adjust, please do as following steps:

- (1) Loosen head H shaft motor stand screw, and move motor backward.
- (2) Rotate motor stand, increase or reduce tensile force of insertion driver belt.
- (3) Loosen the set screw of synchronizing wheel, and adjust the two timing belt wheel to be aligned in one straight line.
- (4) Tighten the set screw, and adjust the tensile force of timing belt into reasonable level, and lock up motor stand screw

(2) Housing synchronizing driver timing belt

If you want to check whether the tensile force is correct, you can put pressure on the driver belt span center—0.45kg (1 pound), the pressure will pull down the driver belt

radian by 12mm.

- (1) Loosen the set screw of shaft housing.
- (2) Loosen the anchor ear of synchronizing wheel, and align each pair of synchronizing wheel axial in one straight line.
- (3) Move the motor stand back or forth to tighten or loosen the clinch timing belt to achieve proper tensile force.
- (4) Loosen anvil shaft stand set screw, move the stand up and down to tighten or loosen the clinch timing belt to achieve proper tensile force.
- (5) Tighten shaft housing set screw.

(3) Adjust the X, Y driver timing belt


Put pressure on the center of X/Y driver belt span—0.45kg (1 pound), the pressure will pull down the timing belt radian by 6mm, if not achieved, please do as following steps to adjust:

- (1) Loosen servo motor stand screw.
- (2) Align the surface of two synchronizing wheels of each timing belt in one straight line.
- (3) Move X shaft servo motor stand back and forth, and move Y shaft servo motor stand left and right to tighten or loosen the clinch timing belt to achieve proper tensile force.
- (4) Tighten motor stand screw.



(4) Adjust the chain motor timing belt

Shown as picture below, loosen the screw and push the assembly up and down to adjust the tightness of belt to achieve proper tightness, then lock the screw.



6) Turn plate adjustment

Adjusting the rotating round plate should be done under normal operation environment temperature; it allows the round plate to rotate smoothly instead of having too much gap. Need to use gauge to support adjustment of rotating round plate. Only trained and professional personnel do following adjustment. Adjusting the driven bearing of round plate surface can allow it to rotate smoothly, there are four driven bearings on each turn plate, the driven bearing at right side is used to adjust centering, and the driven cam at left side is used to adjust over gap. After the turn plate in in place, the two driven wheels will control the turn plate when it rotates.

You should be careful when conduction following steps: do not move the four driven bearing plate at the bottom of turn plate, they are all calibrated precisely and can not be adjusted. (Note: before using gauge to adjust turn plate, the clamp must be work condition)


- 1) Level the workbench.
- 2) Fix the micrometer housing on the surface of shear box cover.
- 3) First adjust the alignment horizontally, then adjust the verticalness, under the mode of diagnose, set the adjustment range as 300mm, adjust speed as 5mm/s. The inspection standard: lead screw travels within 300mm, micrometer reading is within $\pm 0.03\text{mm}$.
- 4) Use diagnose, let the X shaft travels within 300mm, and move repeatedly at the speed of 5mm/s, record the biggest deviation value and the location where the deviation occurs.
- 5) Likely, let the Y shaft travels within 300mm, and move repeatedly at the speed of 5mm/s, record the biggest deviation value and the location where the deviation occurs.
- 6) Compare the reading on X shaft and Y shaft.

- (1) If the four deviation readings at the same direction are same, then need to adjust the turn plate locking main block (S4000-01—07-009).
- (2) If none of the four deviation readings are same, the first step is to adjust turn plate locking main block (S4000-01—07-009) , the rest three steps are adjusting turn table lock clamp(S4000-01—07-027).
- (3) If there is only one deviation, the other three readings are same, then only need to adjust turn table lock clamp (S4000-01—07-027).



7) Adjust the housing


Fasten the left and right spin lead screw with long slider, connect the S4000-01-04-061 and S4000-01-04-062 on lead screw and slider, install two short sliders on the inner slot of S4000-01-04-061 and S4000-01-04-062; Adjust requirement: rotate the lead screw manually, lead screw opens and closes smoothly with proper strength, the two short sliders are sliding at the same horizontal level. You can use leveling rule to measure the alignment of the two sliders when they opens and closes.




Check if both sides are at same level

Leveling ruler


Spin the lead screw, when lead screw opens and close, smooth and even









(1) Adjust the clinch head

Install the O ring to piston bar S4000-01-12-020, and install them inside the clinch air cylinder S4000-01-12-014, seal back cover of the clinch air cylinder S4000-01-12-015, pull the piston bar S4000-01-12-020 manually, piston can move smoothly; when test air system, no air mix and no leak at each joint. You can also duck it in water to see if there is any bubbles to test the air tight, this method is visual and direct, and it is easier to judge there the installation is proper.





Overall housing structure as picture below:




Note: as picture above:

(3) Adjust housing clinch height

Housing clinch height is determined based on PCB board position, first put PCB on turn plate, since housing clinch is synchronized with housing motor, so we need to adjust the servo parameter of housing motor (**when adjusting parameter, please make sure when housing motor is running, the highest point that clinch can reach can not higher than PCB board, otherwise you need to do machinery adjustment to lower down the clinch slightly**) to adjust the height of housing clinch; when adjusting the parameter, you should adjust the parameter with small degree, then check the height of clinch. Normally the highest point that clinch can reach can not be higher than PCB, but the clinch can not be too low either, otherwise it can not reach and clinch. The clinch should be lower than the bottom of PCB board slightly, you can press the center of PCB board, see if the PCB sinks down a little, then it is OK (**you can adjust the height according to actual production requirement**)

(4) Adjust the component lead angle:


When adjusting, you can put housing under the PCB at the proper position, but can not adjust the clinch length; when adjusting, you should turn on the air supply and the housing should be at up position. When the housing is at up position, check if shear and clinch units are aligned horizontally and under the PCB by 0.013~0.25mm.



Adjust movable shear can increase or decrease the clinch angle of component lead. Adjust method as below:

- 1) Turn off air supply
- 2) Push up locking piston nut, move the movable shear to lifted position; when clinch angle is flat and straight, the movable shear S4000-01-12-017 should be shorter than triangle shear S4000-01-12-018 by 0.51mm; at other clinch angle, you can increase this dimension.
- 3) If need other clinch angle, adjust the movable shear position as picture below:
 - (1) Loosen piston travel distance limit locking nut (S4000-01-12-023).
 - (2) Install piston travel distance limit block (S4000-01-12-019)
 - (3) Tighten piston travel distance limit locking nut (S4000-01-12-023)

Adjust outer former and PCB board




Set the clearance between outer former and PCB as 0.25mm (0.010in). When the thickness of PCB changes and causing change to depth locking, then you need to do following adjustment:

- 1) Click “insertion head” in operation system, and turn it off.
- 2) Put one PCB sample board on the PCB clamp.
- 3) Locate X-Y workbench to make PCB right below insertion head.
- 4) Rotate H shaft manually, move insertion head to lifted position.
- 5) Loosen locking screw on the cover of shear S4000-01-04-033.
- 6) Loosen adjust screw and lock nut (KEY 24).
- 7) Rotate H shaft manually, move insertion head to the lowest position.
- 8) Rotate adjust screw, set the height of outer former S4000-01-04-048.
- 9) And S4000-01-04-048 compared to PCB 0.13~0.25mm.
- 10) Tighten screw on the cover of shear S4000-01-04-033.
- 11) Tighten locking nut of adjust screw.

Move the insertion head up and down for several times, and check the gap again

8) Adjust feeder chain

(1) Picture below shows the position of adjust chain



Steps as the picture shows:


1. First loosen the two M5 screw at the left open and close wheel, and tighten the two screws at right side.
2. As picture shows, place the component in the center approximately, left and right chains clamp the component leads tightly, and pull the left chain slowly, and set the two chain clips and component clamped at one line, then tighten the two screws at left side.
3. Enter machine operation system, diagnose interface, click Chr moving forward button slowly, the chain will move slowly. Use the special tool comes along with the machine to test the stability of component (no leaning, no departure, no bend, no drop off, and material is under the shear by certain distance).
4. If the issue of leaning, bend and dropping occue, please adjust based on steps above until the component is stable.

9) Adjust material catching


1. Adjustment of material catching is the key of the whole machine, which affects the insertion quality directly. The parts need to be adjusted for material catching: material catching wheel, sequencer chain of W shape chain clamp, station. **Work procedure: drive station to shear component → component falls on the W shape chain clip precisely and move with sequencer chain → sequencer chain moves**

component to material catching wheel → material catching wheel moves the component to the chain clip of feeder chain, the component is clamped and moved forward, material catching completed.


Shown as picture below: (1) driver station cuts component → component falls on the W shape chain clip precisely and moves forward with sequencer chain



(2) Sequencer chain moves component to material catching wheel




(3) material catching wheel moves the component to the chain clip of feeder chain, the component is clamped and moved forward:




1) Picture below shows adjustment of material catching wheel position:

1). Since the design dimension of two material catching wheel is same, and there are two pin holes on each wheel at the same location, the two pin hole and the center forms a right angle, thus you can put special pin into the pin hole on the wheels to locate, which makes the V shape slot of the two material catching wheels at one line with proper balancing. Based on this theory, when adjust the material wheel, first loosen the locking screw of material catching where shown as picture below, then put the special pin into the holes at the edge; because the screws are loose, the material catching wheel can move left and right. Attention, the joint area of two material catching wheel and feeder chain clip, the distance between left material catching wheel and left feeder chain clip is 2 mm, the distance between right material catching wheel and right feeder chain clip is also 2 mm. After adjustment, tighten the screw of material catching wheel, and pull out the special pin, done.



2) Adjust material catching wheel and feeder chain clip





Theory: due to unique design of feeder chain clip and open and close wheel, when clamp piece of feeder chain clip moves to the joint area shown in the picture, under the force of open and close wheel, clamp pieces of feeder chain clip both hand are opened maximumly, and open position does not change. Since material catching wheel and open wheel are moving in synchronization, when material catching wheel moves to the joint area shown in the picture, component falls on the open feeder chain clip just right; due to unique design of feeder chain clip and open and close wheel, feeder chain

continues to move forward, and the component is clamped and transferred. By this way, the next component falls on next feeder chain clip, thus the component is caught continuously. Because the open position is fixed, you only need to adjust the coordination between material catching wheel and feeder chain clip.


Adjust material catching wheel steps as below:

(1) Loosen the screws marked in the picture below at left side (total 3)

(2) Remove the material shielder marked in the picture below at the right side (it has 3 functions: adjust the component jump amplitude up and down; adjust the component move distance right and left; there are two brushes on the joint area, they can help component to fall on feeder chain clip up more precisely).



(3) After removing the material shielder, fix the special spanner on the shaft as picture above shows, put some components on the sequencer chain, roll the spanner in counterclockwise slowly, at the same time, see if the component can fall on material catching wheel precisely, after approximate adjustment, tighten the screw mentioned in first step, roll the spanner again, now see if if the component can fall on material catching wheel precisely. If component dislocates or drops off, please repeat the step 1.2.3 until it is stable,



(4) After it is stabilized, re-install the material shielder back, adjust the movement distance left and right, amplitude up and down, tightness of brush pressing component , after finishing these 3 steps, fix the spanner on the shaft and roll it at certain speed, see if each component can drop on feeder chain and get clamped tightly.

If component drops off, lead bends or not centering; please adjust the movement distance left and right, amplitude up and down, tightness of brush pressing component. (pay attention to tightness, if too tight, the component lead will get bent, if too loose, the component will not be pressed or drop off, so the tightness needs to be appropriate)到
By now, the material catching is done.

(5) adjust the C shaft original point. After the material is caught, we can move the material on chain toward the upper former slot by 1mm further, now rotate the C shaft optoelectronic switch inspection plate to light up the optoelectronic switch and lock up.

10) Adjust station. Replace the dull left and right main shears that not sharp enough.

(1) Loosen the set screw of main shear, take off the broken shear.

(2) Replace with new shear, and hang on the screw, but do not tighten it.


(3) Put the special fixture on the station as the picture. The tooth at the right side of fixture locates on the station surface, left side of the middle tooth fixes the outer surface of right gear shear, the right side of left tooth fixes the outer surface of left gear shear, and thus, the gear shear is fixed.

(4) Let the main shear blade surface stick to the outer surface of gear shear, and tighten the set screw of main shear.


(5) Remove fixture.

(6) Rotate the main shaft gently, if not smooth, please install the fixture again, loosen the set screw of main shear to make the gap between main shear and gear shear bigger, then tighten the set screw.

(7) Load tape component, rotate main shaft, and check component lead the cutting, if the component lead bent after cut, please reduce the gap between main shear and gear shear again, or replace the main shear.



11) Adjust rear brake belt. Due to servo motor and other mechanic reasons, chain is not steady enough at the moment of start and stop, in order to minimize the unsteadiness; the brake belt is installed at the rear chain shaft. If not steady enough, when adjusting, need to tighten adjustment screw to tight up the brake belt; if the belt is too tight, the chain can not move smoothly, so the belt needs to be adjusted based on actual situation.



2. Adjust value

1) Adjust the parameter in computer

Refer to the introduction at Chapter 3 “each function button on operation interface”

2) Adjust servo parameter

Refer to servo introduction book comes along with machine

3) Adjust switching power this machine uses DC 24, 5 V power supplied by independent switching power.

1) The input voltage of switching power can select between 220V and 110 V, this machine uses 220 V, already set, do not adjust.

2) The output voltage can be adjusted around the nominal value, use multimeter to monitor the output, use slot type screw driver to rotate adjust button, when rotates in clockwise, the output voltage increases; when in counterclockwise, it decreases.

4) Adjust camera

Attention: camera is precision component, it affects the coordinate and H shaft insertion position, break apart or adjust the camera at will is strongly prohibited.

(1). Height height of camera determines the object distance and focus. First do rough adjustment, we set it as a rule: the distance between the camera bottom and PCB is around 148 mm. Then do fine tuning, need to use dedicated measuring scale, and adjust under Visual correction, select 1,5 or 10 mm as unit distance; click once, see if the cursor moves accordingly on the scale of measuring rule once; if not, need to adjust the camera position up and down; if still not right, then adjust the object distance and focus until it is right, then fix the position.

Please pay attention: after moving camera position, the H shaft parameter in “equipment parameter” may also need to be adjusted, because those parameters are set based on camera being “zero point”.

(2) Focus can be adjusted on camera lens. From top to bottom, the first is used to adjust object distance, rotate in clockwise and counterclockwise, the basic standard is the image is clear, then check if cursor move distance is same as measuring scale, then lock up.

(3) object distance can be adjusted on camera lens. From top to bottom, the second is used to adjust object distance, rotate in clockwise and counterclockwise, the basic standard is the image is clear, then check if cursor move distance is same as

measuring scale, then lock up.

2. Equipment Maintenance

1) Daily maintenance

Daily maintenance should be done every 8 operation hours, if the environment is poor, then the machine should be maintained with higher frequency.

Warning: can not use compressed air to blow out debris, otherwise the debris will be blown into all bearings, insertion head, shear/clinch or electric cabinet.

Note: if need to use lubricant to lubricate the machine, you can use 300B lubricant or equivalent.

(1) Add lubricant through the oil filling hole at the top of direction reversing shaft stand to lubricate the shaft sleeve shear/clinch unit.

(2) Use vacuum or brush to clean away the lead debris on shear/clinch unit or machine stable

(3) Clean up the waste in waste bin

(4) Clean up residual in waste pipe

2) Weekly maintenance

Weekly maintenance should be done every 40 operation hours, if the environment is poor, then you should shorten the cycle time.

Air driven lubricate device:

Warning: in lubricate device or air system, phosphate and chlorinated hydrocarbon compound can not be used.

(1) Check oil amount in lubricate device, if necessary, can add 100CKR lubricant.

(2) Shear/clinch unit.

a. Use cloth without soft flocks to wipe ball lead screw.

b. Lubricate ball lead screw slightly.

(3) Insertion head driver device

a. Use cloth without soft flocks to wipe ball lead screw.

b. Lubricate ball lead screw slightly.

(4) Feeder wheel driver device

—— lubricate both ends of connection bar

—— lubricate feeder wheel driver clutch.

—— Check if U shaft limit switch inspection board is loose.

(5) Workbench

—— Wipe and lubricate ball bearing part.

—— Check if limit switch inspection board is tight.

- (1) Check the consistency of insertion head and zero point limit switch.

3) Monthly maintenance

Monthly maintenance should be done every 200 operation hours, if the environment is poor, then you should shorten the cycle time.

- (1) Air driven lubricate device (air control assembly). Through sightglass, check the flow rate of air driven lubricant. Flow rate should be 3~5 drops every 5 minutes. Method to adjust flow rate: rotate the groove screw at the top of lubricate device towards the back of hopper cover, rotate counterclockwise/ clockwise can increase/reduce the lubricant flow rate, at beginning should set it open within 1/4~1/2.

- (2) Shear/clinch unit

——clean rotating lead screw.

——add 20MR oil to the guide rail bottom.

- (3) Insertion head

——add 20MR oil to the inner part.

Note: when breaking apart and assemble insertion head, need to add lubricate oil

- (4) Check the leveling of PCB fixed plate

- (5) Turn plate rotate device

——add 20MR oil to sliding device driver shaft, cam sliding device, stop trigger and set sliding device.

- (6) Workbench

——use oil pot to apply 300SL36 oil on liner guide rail.

——add 300SL36 oil to the path of turn platedriven bearing wheel.

4. Regular Check

- 1) Round plate consistency

- 2) Check insertion head.

- a. Check up and down bearing stands consistency.

- b. Check for inner trap.

- c. Check former travel distance back and forth

- d. Check if the distance between inner and outer formers is same

- e. Set correct C dimension.

- f. Shear and clinch consistency.

- g. Relieve timing belt tensile force.

- h. Housing consistency.

- i. Centering of up and down insertion heads.

j. Clinch angle.


5. Air driven part maintenance

A set of air driven device, if not get maintained properly, it will be damaged too early or break down frequently, and shorten working life greatly. When maintaining air driven device, if accident signal is seen, you need to take countermeasure timely to minimize or prevent breakdown from occurring, and prolong the working life of component and system. Thus, company should create maintenance management regulation for air driven device, strengthen management and education, and manage it strictly.

The key task of maintenance is to ensure supply clean and dry compressed air to air driven system, ensure air driven system seal tightness, ensure oil spray lubricate component to be lubricated properly, ensure air driven component and system to operate in regulated work conditions (like using pressure, voltage, etc), to make sure air driven execute assembly work according to requirement.

1) Air cylinder maintenance

The structure and theory of air cylinder is shown as picture1.




picture1

- 1. rear cylinder cover 2. Seal ring 3. buffering seal ring 4. Piston seal ring 5. Piston
- 6. buffering plunger piston 7. Piston bar 8. Cylinder barrel 9. Buffering throttle 10. guiding sleeve
- 11. front cylinder cover 12. dust-proof seal ring 13. Magnet 14. guiding ring

After break down air cylinder, first clean each component, then lubricate or seal one by one.

Piston maintenance air cylinder piston is pushed by air pressure and slides in side the barrels, which requires high flexibility of piston as well as good seal between piston and cylinder. The seal is achieved by YX shape seal ring, thus the YX shap seal ring is quick-wear part, please see its structure in picture 2.



Picture 2: YX shape seal ring

There are two lips of same length at the fracture surface of YX shape seal ring, the seal ring is installed in the slot of piston, when its right side is pushed by air pressure, the seal ring lip will open due to the pressure, and stick to cylinder barrel tightly to achieve good seal. Please observe closely after the air cylinder is broken apart, if the YX shape seal ring lip has been worn out, the you should remove it and replace with a new lip; apply lubricate oil. Besides, the buffering plunger piston touches with cylinder cover frequently, so it also needs to be applied with lubricate oil.

Cylinder cover maintenance

When the air cylinder is working, piston will hit cylinder cover, so the cylinder cover buffering seal ring is quick-wear part; if the buffering seal ring is worn out badly, the buffering effectiveness will be affected due to poor seal between buffering plunger piston and buffering seal ring before the air cylinder stops. After using air cylinder for long time, it usually required to replace seal ring, and apply lubricate oil.

Cylinder cover buffering tends to be ignored easily, please be careful, screw down the buffering throttle, use thin iron wire to clean the buffering hole carefully (be careful do not damage throttle thread), otherwise, buffering venting hole will be blocked, which may cause piston bar can not be at proper place.

Cylinder barrel maintenance

Apply lubricate oil onn the inside wall of cylinder barrel, and install piston bar, at the same time pull and push it several times to ensure good lubrication and seal quality between cylinder barrel and piston.

After maintenance, you can assemble it.

—— When maintaining the air cylinder, you should pay attention to following issues:

After air cylinder is broken apart, you should first clean the cylinder barrel, piston, piston bar and cylinder cover, and remove the rust on surface.

- (1) The lubricate oil can not contain solid additive.
 - (2) Select seal material according to the specific work, better choose polytetrafluoroethylene (teflon), the friction factor of this material is low(about 0.04), corrosion resisting, so the material can work within the temperature range of $-800^{\circ}\text{C}\sim +2000^{\circ}\text{C}$.
 - (3) When installing YX shape seal ring, be careful about the installing direction.
- 2) Electromagnetic valve maintenance
- (1) The best method to make electromagnetic valve work reliably with long life is to do regular examination and repair one or two times per year. The following four kinds of situations inside electromagnetic valve are reason for electromagnetic valve abnormal and short work life.
 - A. medium changes during usage process
 - B. rust inside jointer
 - C. air compressor oil oxidizes, producing carbon granule, oil tar and so on, get into pipes
 - D. impurities like dust and dirt inside pipes
 - (2) Breaking apart electromagnetic valve coil block is not recommended.
 - (3) When break apart electromagnetic valve for cleaning, you can use some liquid like kerosene and trichloroethylene and so on, but please be careful the runner part may swell, so you need to replace the rubber part.
 - (4) When breaking apart the equipment for cleaning, please place the components in order, which helps you to install later.
- 3) Air supply filters use cleaning cloth to wipe and clean every three months.
- 4) Air lubricator better fill the air lubricator once every week, when filling, please pay attention to the oil reduce status. If the oil consumption amount is too little, you should adjust the drops of oils; if after adjusting, the drops of oils is still too little, then you should check if the oil mouth is installed resersely, and oil tunnel is blocked or not, whether the air lubricator specification is proper.

6.Dust cleaning

- Warning: can not use compressed air to blow out debris, otherwise the debris will be blown into all bearings, insertion head, or electric cabinet, which will affect the normal work of machine.
 - Before cleaning the dust, must turn off the pwer of computer and machine
- 1) Computer mainframe check the cooling fan of mainframe once every month, use cleaning cloth or brush to remove dust.

- 2) Servo, motor check servo shell and its cooling fan once every month, use cleaning cloth or brush to remove dust.
- 3) Machine inside use cleaning cloth or brush to clean once every week, or use cleaning agent to wipe, and pay attention to moistureproof.
- 4) Machine shell use cleaning cloth to clean once every week. Using organic solvent to wipe is strictly prohibited to avoid damage to the paint on equipment shell. Please you must never use plate washer water, IPA to clean the printed letter.

Chapter 6 Basic Error Analysis and Solutions

1. Basic error analysis and solutions

Skills: first need to identify which part causes the breakdown, electricity, air system, machinar, or computer. Then check whether electricity, air, or power source are introduced or not, are they nominal values. Next check the connection or demountable section connected or not, or locked stably (wire connector, synchronizing wheel.....). Check whether safety switch, protective switch, limit switch are under protective locking (scram switch, protective tube, limit optoelectronic switch, electric leakage switch, air-brake switch).

Failure Area	Symptom	Root Cause	Failure Resolution
Computer	computer and display can not open	panel computer power switch broken orconnection wire broken	Replace or connect again

	Can not turn on computer, but display normal	<ol style="list-style-type: none"> 1. Check internal memory stick 2. Check if mouse and key are connected reversely 3. system error 	<ol style="list-style-type: none"> 1. use eraser to rub the gold bar on internal memory stick, replace internal memory sticks lot or replace internal memory stick 2. if connected reversely, then correct it 3. re-install system, contact ciencgo
	Mainframe can work normally but no display	Check internal memory stick for loose connection or CPU for poor connection	use eraser to rub the gold bar on internal memory stick, or replace CPU
	Shut off automatically after turn on the computer less than 10 minutes	CPU cooling fan loose, broken, or power voltage unstable	Replace CPU cooling fan or check power circuit
	excel file format incompatible, can not open operation system	Infected with virus, Office has been damages	Use latest updated anti-virus software to kill the virus, delete all the excel files, re-install Office
XY servo system	motor does not move	Let servo exit from power connection, pull off the wire between servo and motor, push XY Assembly slightly, see if it can move or not	
		limit inspection board touches limit optoelectric switch	Retreat the machine to original reposition, exit from limit position

		servo has no monophase 200 V output	Check servo enable singal, I/O, replace servo
		Connector between servo and motor does not actuate	Make emergency stop reposition, replace connector
	motor moves but abnormal	motor broken	replace
		Computer error (example:drift phenomenon)	
		synchronizing wheel not tighten	Tighten it
		Improper parameter setting	set up again
		timing belt aging	replace
		servo or motor error	check and repair or replace

Failure Area	Symptom	Root Cause	Failure Resolution
Image	light source no light	5V power error	Check 5V switch power, relay, wire connector
	light source not bright enough	5V voltage too low	Adjust standard
		LED broken	replace
	Vedio no image	Singal wire error	Re-connect or replace
	Image vague, not clear	camera not adjusted well	Adjust aperture
		light source not bright enough	Check 5 V or LED
		camera parameter setting in the system incorrect	Tone up again andadjust exposure time
		Board too dirty	clean

Machine back to zero position	When machine zeros, click zeros, machine does not move	Press down emergency stop switch	Turn on the emergency stop switch in clockwise, turn on 24V power
		Organic glass door protective switch on	Turn off the organic glass door protective switch, make stop switch red light extinguish
		turn table small board broken	replace turn table small board
	zero position switch is triggered, machine does not stop, continue to run	zero position optoelectronic switch broken	replace optoelectronic switch
feed	feed length not same	feed device is not adjusted well, or component broken	Check and confirm the error and adjust again
		shaft joint loose	Check if shaft joint set screw and anchor ear are loose or tightened, if trips, replace the worn out part
	Block when feeding	Feeder stretched part is not adjusted well	Adjust again
		feed pipe is blocked	Clean the pipe
		S4000-01-04-054 broken, causing hook knife no elasticity	replace spring S4000-01-04-054
		servo parameter setting improper	set up again
		S4000-01-04-065 broken	replace left bottom shear S4000-01-04-065
Coordinate displacement	After adjustment, good for some time, then displace	timing belt too loose	adjust timing belt tightness
		X.Y shaft screw under the turn plate loose	Check and tighten the loose screw

		anchor ear not tight	replace anchor ear
		encoder singal wire broken	replace
		motor or driver broken	replace

Failure Area	Symptom	Root Cause	Failure Resolution
Component falls down	Component falls down	S4000-01-04-058 , S4000-01-04-059 shakes heavily	Replace S4000-01-04-055 or S4000-01-04-056, S4000-01-04-057
		Inner and outer formers broken	Replace
		clinch air cylinder poor seal	Check and repair
Shear	Shear but not bend	Housing cylinder breakdown	Replace
	Not shear	Electronic valve that driving housing cylinder breakdown	Check and replace
		Hollow pin brake or loose	Check and replace
		S4000-01-12-017 or S4000-01-12-018 worn out	Replace blade
Lead	Lead is bent , but not sheared	program coordinate problem	Calibrate program coordinate
Insertion	wrong insertion	S4000-01-04-040 pin loose	Replace S4000-01-04-040
		Forming issue	Check gap between up former and low former and wearing degree,replace
		S4000-01-04-011worn out , big gap	Replace S4000-01-04-011

Turn plate	Turn plate lock not release , turn plate not move	Electronic valve that driving turn plate breakdown	Replace
		Turn wire breaks	Use multimeter to check and replace
		The two small cyliders that releasing turn plate are loose ,causing lock device can not open enough to drive turn plate	Check and adjust again
		Turn table motor breakdown	Replace

1)Computer basic error analysis and solutions

Skills: first need to identify which part causes the breakdown, electricity, air system, Assembly or computer. Then check whether electricity, air, or power source are introduced or not, are they nominal values. Next check the connection or demountable section connected or not, or locked stably (wire connector, synchronizing wheel.....). Check whether safety switch, protective switch, limit switch are under protective locking (scram switch, protective tube, limit optoelectronic switch, electric leakage switch, air-brake switch).


(1) Installation of driver

Normally for a hard disk that just get system installed or recovered ,still there are several drivers not installed, such as mainboard, display card, sound card, USB controller, etc.


a. Installation method:

First check the driver that not installed yet, go to device manager, see picture as below, if there is mark of “!” or yellow “?” in the yellow circle for the option, then it means the driver of the option is not installed. Right click the option, and install the driver by selectting ”Update Driver” or using the disk that come with computer (shown as following picture).





This screen shows the driver is installed for control card (PISO-P32C32 and DMC1000)



b. File backup

In order to avoid loss of production data, we recommend every two or three days, use clean USB flash disk that without virus to copy the Southern Machinery data folder and camera folder as backup.

If the machine shows “excel table incompatible” or “file format incorrect”, please conduct overall virus detection and destruction under safe mode, and install Office software again, then delete all files that have excel table.

c. Set up of Display

1. Display color: 32 bits true color
2. Screen resolution: 1024×768 pixel
3. Set Screen Protection as “Non”, and Power Management as “Always on”.

Attention: install and run antivirus software casually, because when AI is working, it needs to access to hard disk file frequently, and antivirus program usually first check read-write file, which affecting the AI performance and system stability. If the computer is suspicious of virus, you can create and install antivirus software, after destroying virus, uninstall the antivirus software or stop running it.

Warning: if data exchange with outside is needed, please make sure that outside device (USB flash disk, CD, Floppy disk) does not contain virus!

d. Basic error analysis and solution

Skill: first need to identify which part causes the breakdown, electricity, air system, Assembly or computer. Then check whether electricity, air, or power source are introduced or not, are they nominal values. Next check the connection or demountable section connected or not, or locked stably (wire connector, synchronizing wheel.....). Check whether safety switch, protective switch, limit switch are under protective locking (scram switch, protective tube, limit optoelectronic switch, electric leakage switch, air-brake switch).

(1) Unable to turn on computer and display

◆error analysis: usually happen when UPS breakdown and no power in store, or panel power button or power wire burns out or has poor connection.

◇Solution:

Step 1: check whether computer power wire is connected to UPS, and whether UPS is working normally. Connect the power of computer and display to outside.

Step 2: check whether soldering joint between panel button and connection wire is loose or connected wrong; connect the button wire again or replace the button.

Step 3: check power wire joint loose or connected poorly, replace power wire or pull out and insert power wire again.

(2) Unable to turn on computer mainframe, but display is normal

◆error analysis: 1. check memory bank for copper foil falls off or IC burnout
2. Check mouse and keyboard linked correctly 3. System is destroyed or crashed.

◇Solution:

Step 1: use clean eraser to clean copper foil on memory bank, replace memory slot and install it on mainframe again, or replace memory bank.

Step 2: switch the socket of mouse and keyboard or pull out mouse and keyboard.

Step 3: system is destroyed by virus or by people (delete system file by mistake), install system again or recover the system.

(3) Mainframe can work normally, but there is no display

◆error analysis: this problem usually occurs on memory bank, mainboard, and display card; also it may occur on displayer.

◇ Solution:

- Step 1: remove memor bank, clean up the dust on mainboard, use clean rubber to rub the copper foil on memory bank, change memory slot and install again on mainboard, or replace memory bank.
- Step 2: if there is discrete graphic card, then remove it and clean the dust, and install it on mainboard again.
- Step 3: remove CPU, memory bank from mainboard and install again, or replace mainboard directly.
- Step 4: pull out the vedio connecting wire andplug again, or replace.
- (4) Computer shuts down or restarts automatically after operating less then 10 munites, or restarts frequently; Turn on emergency stop switch, computer shuts down.
- ◆error analysis: this problem usually occurs due to poor CPU heat emission or unstable power voltage. For turn on emergency stop switch, computer shuts down, it is because of the emergency stop switch is pressed for too long time.

◇ Solution:

- Step 1: CPU cooling fan is stuck by dust or feed snap can not rotate, replace CPU cooling fan.
- Step 2: the thermal conductive silicon under CPU cooling fan heat emission fin is dried up, tear up CPU cooling fan heat emission fin and apply thermal conductive silicon on the surface evenly.
- Step 3: Turn on emergency stop switch, computer shuts down or restart, UPS voltage is not stable, seperate the power of computer and machine, do not link the two both to UPS.
- (5) turn on computer operating system, Execl file can not be recognized.
- ◆error analysis: this issue is difficult to diagnose cause. 1. may caused by Office2000 File Format Converters damage; 2. Office is infected by virus; 3. The computer is shut off illegally or accidentally, and data is damaged.

◇ Solution:

- Step 1: use lastest anti-virus software to detect and kill virus, install Office2000 software again, delete all previous Execl file.
- Step 2: Use “ExeclRecovery” to recover damaged Execl 2000 files. This software will add recover program to Execl software automatically, showing the command of “Recovery” is added under “File” menu, it will open damaged file in the way of automatic recovery.
- Step 3: if all above methods can not recover the file, try to re-install or recover the system.
- (6) Insertion head back to zero position, no movement.
- ◆error analysis: usually caused by optoelectronic switch, signal wire, control card or IO board.

◇ Solution:

- Step 1: distinguish the serial no. of control card, replace data wire for control card, inspect control card’s signal staus or replace control card.
- Step 2: check IO board for loose screw, or burnout, or IC burnout; replace IO board.
- Step 3: check if optoelectronic switch is blocked.
- Step 4: check if sensor is at best place or falls off.
- (7) Blue screen code: 0x0000007B:INACCESSIBLE_BOOT_DEVICE
- ◆error analysis: in starting procedure, Windows can not visit system

partition or. It usually happens after mainboard is replaced; start for the first time, mainly because IDE controllers for new mainboard and old mainboard are equipped with different chip. Sometimes, it may be caused by virus or hard disk damage.

◇ Solution:

Usually it can be solved by starting computer with installation disk and conduct recovery installation. For virus, can use DOS version anti-virus software to kill the virus (kv2005DOS version is available for download in main station). If hard disk has problem, please install it into other computer, and use "chkdsk /r" to check and correct disk error.

(8) Open the computer and skip Windows2000 interface scroll bar, black screen, re-start automatically or shut down.

◆ error analysis: 1.Windows system file is damaged or crushes; 2. hard disk damage causing Windows can not start normally.

◇ Solution:

Step 1: use system installation disk to recover the system.

Step 2: re-install the system or recover system.

(9) Open operating software, error code: E0001, E0002, E0003, E0004

◆ error analysis: E0001 is because of the hard disk is not registered. E0002 is caused by the same reason as E0001. E0003, safetydog is not installed properly; E0004, there is no operation board driver.

◇ Solution:

Step 1: register the hard disk installed in system at Southern Machinery.

Step 2: make sure the safety dog is installed properly.

Step 3: install all drivers, and the two files in "My computer" D disk installation board.

Step 4: check files in Southern Machinery for any miss of following files: 0001 bitmap image, alast, aslast, rlast, mdlast, slast, camera, original point debug, TESTT, equipment parameter, component parameter.

(10) turn on machine operating software; the tip that there is no relevant user lock pops out.

◆ error analysis: 1. safety dog is not installed; 2. safety dog is loose, poor connection; 3. if there is USB extended wire, it may burnout.

◇ Solution:

Step 1: re-install safety dog to USB slot.

Step 2: replace USB extended wire or change to another USB slot, connect safety dog again

(11) Driver initializing error!!!

◆ error analysis: board DMC1000, PISO-P32C32 or PISO-C64 driver is not installed.

◇ Solution:

Usually the problem can be solved by installing board driver according to above **Installing Method of Movement Control Card** and re-start the computer.

(12) Run-time error "1004" or Run-time error "91"

◆ error analysis: run-time error, code 1004, lack of alast.xls (Axial) file or rlast.xls (Radial) file in Southern Machinery data.

◇ Solution:

Open "My computer" D disk Southern Machinery data and check if alast.xls(Axial) file or rlast.xls (Radial) file exists, copy one alast.xls (Axial) file or rlast.xls(Radial) file into it from USB, or copy one program named by alast.xls (Axial) file or rlast.xls(Radial) file.

(13) Run-time error "53 can not find dmc1000.dll

◆ error analysis: this computer has not been registered at Southern Machinery

◇ Solution:

Please contact Southern Machinery technician, register the hard disk for the computer, and debug the software program.

(14) P Card Error; Driver initializing error!!!

◆ error analysis: run-time PISO control card initialize error, PISO control card is not readable.

◇ Solution:

At control panel- system –hard ware- device manager, check if PISO-P3C32 control card driver is installed or not, or remove the PISO control card and install again.

(15) Error code SN, please contact Southern Machinery; or error code SK, please contact Southern Machinery (1000)

◆ error analysis: 1.this hard disk is not registered with Southern Machinery software; 2.safety dog is not installed properly, can not detect driver; 3. log in user name has been changed.

◇ Solution:1. Check if the hard disk is formatted and the system is installed again; 2. Check if safety dog is pulled out; check in control panel, if the login name for user account has been changed or not.

(16) Run-time error "91", Object variable or with block variable not net

P Card Error, Only one Card in system (3000)

◆ error analysis: Run-time error "91", target is variable or block is invariant, P Card Error, Only one Card in system.

◇ Solution: go to D disk, equipment parameter in Southern Machinery data, change the last item, the quantity for dispenser.

(17) When exit from software or use certain function, it show: Please exit EXECL running.

◆ error analysis: check Windows, if EXECL file is opened, or EXECL.exe process does not stop in task manager.

◇ Solution:

1. Close the open EXECL file in Windows


2. Use combination key Ctrl+Alt+Del to open task management, stop the EXECL.exe process.



3. Copy Southern Machinery data and necessary software to "My computer" D disk, and overlap previous data.


CPU and cooling fan



PISO-P32C32









Chapter 7 Machine Circuit Schematic

1 .Circuit wiring diagram




Note ①: SSR1=Solid-state relay 1 KA1=3P relay 1 (forward) Note ②: ①—DC motor
 SSR2=Solid-state relay 2 KA2=3P relay 2 (reverse) 1-11—Relay contact pin No.
 KA3=2P relay 1 (emergency stop) ②③—Wire mark
 KA4=2P relay 2 (flashlight)


Note ③: ES: emergency stop switch self lock
 SB1: start switch self return button
 SB2: stop switch self lock button
 SB3: jump wire make up self return
 SB4: start switch self return button
 SB5: stop switch self lock button



XG-4000 Axial Insertion Machine Electronic Component Diagram



XG-4000 Axial Inserter I/O Board Wiring Diagram



三.I/O A board signal comparison chart 1

I/O A board wire connection chart					
Interface board	Signal mark	Signal name	Interface board	Signal mark	Signal name
1			35	PULC+	C servo X5--3
2	PULX+	X servo X5—3	36	PULC-	C servo X5--4
3	PULX-	X servo X5—4	37	DIRC+	C servo X5--5
4	DIRX+	X servo X5—5	38	DIRC-	C servo X5--6
5	DIRX-	X servo X5—6	39	PULChn1+	Chn1 servo X5—3
6	PULY+	Y servo X5—3	40	PULChn1-	Chn1 servo X5—4
7	PULY-	Y servo X5—4	41	DIRChn1+	Chn1 servo X5—5
8	DIRY+	Y servo X5—5	42	DIRChn1-	Chn1 servo X5—6
9	DIRY-	Y servo X5—6	43	OUT1	Flashlight
10	ELX+	X+ limit	44	OUT2	Spare
11	XLX-	X- limit	45	OUT3	green light
12	SDX+	X+ slow down	46	OUT4	Yellow light
13	SDX-	X- slow down	47	OUT5	Red light
14	ORGX	X original point	48	OUT6	clinch
15	ELY+	Y+ limit	49	OUT7	Turn plate lock open
16	XLY-	Y- limit	50	OUT8	Turn plate clamping roller
17	SDY+	Y+ slow down	51	OUT9	Clockwise
18	SDY-	Y- slow down	52	OUT10	Counterclockwise
19	ORGY	Y original point	53	OUT11	Blow away waste leg
20	ELC+	C+ limit	54	OUT12	Air source
21	ELC-	C- limit	55	IN5	insertion inspection 1
22			56	IN6	insertion inspection 2
23			57	IN7	Start
24	ORGC	C original point	58	IN8	Stop
25	ELXChn1+		59	IN9	sequencer inspection
26	ELXChn1-		60	IN10	
27			61	IN11	Turn plate in place
28			62	IN12	Turn plate at zero position
29	ORHChn1	Chn1 original point	63	IN13	
30	IN1	Emergency switch	64	IN14	
31	IN2	Head safety	65	IN15	
32	IN3	Protecting cover safety	66	GND	24VDC-

33	IN4	Head switch	67	VDD	24VDC+
34	GND	Groundwire	68	IN16	
	X	X motor			
	Y	Y motor			
	C	C motor			
	Chn1	Chn1 motor			

I/O B board signal comparison chart 2

I/O B board wire connection chart					
Interface board	Signal mark	Signal name	Interface board	Signal mark	Signal name
1			35	PULChn2+	Chn2 servo X5—3
2	PULH+	H servo X5—3	36	PULChn2-	Chn2 servo X5—4
3	PULH-	H servo X5—4	37	DIRChn2+	Chn2 servo X5—5
4	DIRH+	H servo X5—5	38	DIRChn2-	Chn2 servo X5—6
5	DIRH-	H servo X5—6	39	PULW+	W servo X5—3
6	PULB+	H servo X5—3	40	PULW-	W servo X5—4
7	PULB-	H servo X5—4	41	DIRW+	W servo X5—5
8	DIRB+	H servo X5—5	42	DIRW-	W servo X5—6
9	DIRB-	H servo X5—6	43	OUT1	Servo enabling
10			44	OUT2	
11			45	OUT3	
12			46	OUT4	
13			47	OUT5	
14	ORGC2	C2 original point	48	OUT6	
15			49	OUT7	
16			50	OUT8	
17			51	OUT9	
18			52	OUT10	
19	ORGB	B original point	53	OUT11	
20			54	OUT12	
21			55	IN5	
22			56	IN6	
23			57	IN7	
24	ORGH	H original point	58	IN8	


25			59	IN9	
26			60	IN10	
27			61	IN11	
28			62	IN12	
29			63	IN13	
30	IN1		64	IN14	
31	IN2		65	IN15	
32	IN3		66	GND	24VDC-
33	IN4		67	GND	24VDC+
34	GND	Groundwire	68	N16	
	H	head motor			
	B	housing motor			
	CHn2	feeder motor			
	W	Jump wire motor			

XG-4000 Axial Insertion Machine I/O Signal Sheet					
Board A Signal Sheet			Board B Signal Sheet		
Port	Signal mark	Servo Signal port	Port	Signal mark	Servo Signal port
A-X5-1	PUL X+	X servo X5-3	B-X5-1	PUL H+	H servo X5-3
A-X5-2	PUL X-	X servo X5-4	B-X5-2	PUL H-	H servo X5-4
A-X5-3	DIR X+	X servo X5-5	B-X5-3	DIR H+	H servo X5-5
A-X5-4	DIR X-	X servo X5-6	B-X5-4	DIR H-	H servo X5-6
A-X5-6	EL X+	X+ extreme	B-X5-6	SD H+	H+ extreme
A-X5-7	EL X-	X- extreme	B-X5-7	SD H-	H- extreme
A-X5-8	SD X+	X+ slow down			
A-X5-9	SD X-	X+ slow down	B-X6-1	PUL B+	B servo X5-3
			B-X6-2	PUL B-	B servo X5-4
A-X6-1	PUL Y+	Y servo X5-3	B-X6-3	DIR B+	B servo X5-5
A-X6-2	PUL Y-	Y servo X5-4	B-X6-4	DIR B-	B servo X5-6
A-X6-3	DIR Y+	Y servo X5-5			
A-X6-4	DIR Y-	Y servo X5-6	B-X8-1	PUL W+	W servo X5-3
A-X6-6	EL Y+	Y+ extreme	B-X8-2	PUL W-	W servo X5-4
A-X6-7	EL Y-	Y- extreme	B-X8-3	DIR W+	W servo X5-5
A-X6-8	SD Y+	Y+ slow down	B-X8-4	DIR W-	W servo X5-6
A-X6-9	SD Y-	Y+ slow down			
A-X7-1	PUL C+	U servo X5-3			
A-X7-2	PUL C-	U servo X5-4			
A-X7-3	DIR C+	U servo X5-5			
A-X7-4	DIR C-	U servo X5-6			
A-X7-6	SD C+	U+ extreme			
A-X7-7	SD C-	U- extreme			
A-X8-1	PUL Chn+	C servo X5-3			
A-X8-2	PUL Chn-	C servo X5-4			
A-X8-3	DIR Chn+	C servo X5-5			
A-X8-4	DIR Chn-	C servo X5-6			

XG-4000 Axial Insertion Machine Signal Distribution Diagram									
A			B			C			
37P			37P			37P			
	24VDC-	1		24VDC-	1		24VDC-	1	
X-A-36	36 Station 16 driver	3	X-B-36	36 Station 32 driver	3	X-C-36	36	36	2
X-A-35	35 Station 15 driver	4	X-B-35	35 Station 31 driver	4	X-C-35	35	35	3
X-A-34	34 Station 14 driver	5	X-B-34	34 Station 30 driver	5	X-C-34	34	34	4
X-A-33	33 Station 13 driver	6	X-B-33	33 Station 29 driver	6	X-C-33	33	33	5
X-A-32	32 Station 12 driver	7	X-B-32	32 Station 28 driver	7	X-C-32	32	32	6
X-A-31	31 Station 11 driver	8	X-B-31	31 Station 27 driver	8	X-C-31	31	31	7
X-A-30	30 Station 10 driver	9	X-B-30	30 Station 26 driver	9	X-C-30	30	30	8
X-A-29	29 Station 9 driver	10	X-B-29	29 Station 25 driver	10	X-C-29	29	29	9
X-A-28	28 Station 8 driver	11	X-B-28	28 Station 24 driver	11	X-C-28	28	28	10
X-A-27	27 Station 7 driver	12	X-B-27	27 Station 23 driver	12	X-C-27	27	27	11
X-A-26	26 Station 6 driver	13	X-B-26	26 Station 22 driver	13	X-C-26	26	26	12
X-A-25	25 Station 5 driver	14	X-B-25	25 Station 21 driver	14	X-C-25	25	25	13
X-A-24	24 Station 4 driver	15	X-B-24	24 Station 20 driver	15	X-C-24	24	24	14
X-A-23	23 Station 3 driver	16	X-B-23	23 Station 19 driver	16	X-C-23	23	23	15
X-A-22	22 Station 2 driver	17	X-B-22	22 Station 18 driver	17	X-C-22	22	22	16
X-A-21	21 Station 1 driver	18	X-B-21	21 Station 17 driver	18	X-C-21	21	21	17
	20 24VDC-	19		20 24VDC-	19		20 24VDC-	19	


Input station circuit connection chart(30 stations)P32C32 card					
CON1	(Pin port 37 of card)				
Interface board	Signal mark	Signal name	Interface board	Signal mark	Signal name
1	CND	24V(-)	20	CND	24V(-)
2	INPUT0	Station 1 input	21	OUTPUT0	Station 1 output
3	INPUT1	Station 2 input	22	OUTPUT1	Station 2 output
4	INPUT2	Station 3 input	23	OUTPUT2	Station 3 output
5	INPUT3	Station 4 input	24	OUTPUT3	Station 4 output
6	INPUT4	Station 5 input	25	OUTPUT4	Station 5 output
7	INPUT5	Station 6 input	26	OUTPUT5	Station 6 output
8	INPUT6	Station 7 input	27	OUTPUT6	Station 7 output
9	INPUT7	Station 8 input	28	OUTPUT7	Station 8 output
10	INPUT8	Station 9 input	29	OUTPUT8	Station 9 output
11	INPUT9	Station 10 input	30	OUTPUT9	Station 10 output
12	INPUT10	Station 11 input	31	OUTPUT10	Station 11 output
13	INPUT11	Station 12 input	32	OUTPUT11	Station 12 output
14	INPUT12	Station 13 input	33	OUTPUT12	Station 13 output
15	INPUT13	Station 14 input	34	OUTPUT13	Station 14 output
16	INPUT14	Station 15 input	35	OUTPUT14	Station 15 output
17	INPUT15	Station 16 input	36	OUTPUT15	Station 16 output
18	COM2A	Signal ground	37	VC	Station 24V(+)
19	COM2B	Signal ground			
CON2	(Lead pin 37)				
Interface board	Signal mark	Signal name	Interface board	Signal mark	Signal name
1	CND	24V(-)	20	CND	24(-)
2	INPUT16	17 input	21	OUTPUT16	17 output
3	INPUT17	18 input	22	OUTPUT17	18 output
4	INPUT18	19 input	23	OUTPUT18	19 output

5	INPUT19	20 input	24	OUTPUT19	20 output
6	INPUT20	21 input	25	OUTPUT20	21 output
7	INPUT21	22 input	26	OUTPUT21	22 output
8	INPUT22	23 input	27	OUTPUT22	23 output
9	INPUT23	24 input	28	OUTPUT23	24 output
10	INPUT24	25 input	29	OUTPUT24	25 output
11	INPUT25	26 input	30	OUTPUT25	26 output
12	INPUT26	27 input	31	OUTPUT26	27 output
13	INPUT27	28 input	32	OUTPUT27	28 output
14	INPUT28	29 input	33	OUTPUT28	29 output
15	INPUT29	30 input	34	OUTPUT29	30 output
16	INPUT30		35	OUTPUT30	
17	INPUT31		36	OUTPUT31	
18	COM2A	Signal ground	37	VC	24(+)
19	COM2B	Signal ground			



S4000 Pneumatic Connection Chart


2. Computer control chart




Axial Machine Computer Control Diagram


Chapter 8 Machinery Break down chart

1.Machinery plane sketch:






2.Component list




Head Assembly Sketch



Head Assembly Break down Sketch 1

Head component list 1		
No.	Name	Part #
1	Head stand	S4000-01-04-001
2	Weld block	S4000-01-01-014
3	Stand rack (partial)	S4000-01-01-008
4	Head stand seat pad	S4000-01-04-072
5	feederchain wheel holder 2	S4000-01-11-004
6	Optoelectronic switch holder	S4000-01-04-016
7	Optoelectronic switch EE-SX670	
8	H shaft Optoelectronic switch holder	S4000-01-04-070
9	H shaft adjust wheel	S4000-01-04-074
10	H shaft zero position spacer	S4000-01-04-013
11	H shaft detection piece 1	S4000-01-04-014
12	H shaft gear rack	S4000-01-04-007
13	H shaft connector	S4000-01-04-011
14	H shaft detection piece 2	S4000-01-04-071
15	H shaft connecting pin	S4000-01-04-075
16	H transmitting gear shaft	S4000-01-04-008
17	H bearing housing	S4000-01-04-009
18	bearing 6004ZZ	S4000-01-04-085
19	H bearing cover	S4000-01-04-010
20	H shaft driven synchronizing wheel	S4000-01-04-006
21	Anchor ear D14	S4000-01-11-036
22	feeder chain wheel housing 1	S4000-01-11-003
23	18 toothed chain wheel	S4000-01-11-014
24	bearing TLA1416	S4000-01-11-039
25	feederchain wheel fulcrum bar 2	S4000-01-11-007
26	POM bushing 1	S4000-01-11-025
27	H shaft liner guide	S4000-01-04-083
28	H shaft guide rail mounting plate	S4000-01-04-002
29	Timing belt 240L*28	S4000-01-04-084

30	H shaft motor housing	S4000-01-04-004
31	Fixed housing	S4000-01-04-003
32	H shaft motor synchronizing wheel	S4000-01-04-005
33	1000W servo motor	
34	Cup head screw M8×25	
35	Cup head screw M8×30	
36	Cup head screw M6×35	
37	Cup head screw M4×35	
38	Cup head screw M8×35	
39	Cup head screw M4×10	
40	Round head screw M5×12	
41	Cup head screw M4×12	
42	Cup head screw M3×20	
43	set M4×10	
44	cup head screw M4×12	
45	cup head screw M6×30	
46	set M5×10	
47	cup head screw M5×10	
48	cup head screw M4×20	
49	set M5×5	




Head Assembly Break down Sketch 2


Head component list 2		
No.	Name	Part #
1	right hand mainbody	S4000-01-04-021
2	down U shaft lead screw right hand accessory	S4000-01-04-025
3	right hand long stick	S4000-01-04-022
4	Optoelectronic switch EE-SX670	
5	H shaft optoelectronic inspection holder	S4000-01-04-015
6	left hand long stick	S4000-01-04-020
7	Head aluminum block	S4000-01-04-023
8	feederchain wheel fulcrum bar 5	S4000-01-11-010
9	bearing BA68ZZ	S4000-01-11-040
10	10 toothed chaine wheel	S4000-01-11-033
11	anchor ear	S4000-01-03-017
12	left hand mainbody	S4000-01-04-019
13	bearing with snap spring 5200ZZ	S4000-01-04-086
14	U bearing cap	S4000-01-12-001
15	nut M10*1	S4000-01-04-018
16	Locating anchor ear	S4000-01-04-068
17	U shaft left and right spin lead screw	S4000-01-04-017
18	low U shaft lead screw left accessory	S4000-01-04-024
19	left shear stand	S4000-01-04-026
20	left outer former guide	S4000-01-04-062
21	feeder pipe	S4000-01-06-020
22	Left low shear	S4000-01-04-065
23	Right hand former shear stand	S4000-01-04-056
24	Right former piece	S4000-01-04-058
26	left former piece	S4000-01-04-059
27	left hand former shear stand	S4000-01-04-057
28	locating pin	S4000-01-04-076
30	LH shear installing cover	S4000-01-04-061
31	Outer former shear move deep stop block	S4000-01-04-037

32	spring lamination	S4000-01-04-054
33	Shim to press spring lamination	S4000-01-04-053
34	Shear box	S4000-01-04-031
35	ball slot inside shear box	S4000-01-04-045
36	Shear box anti-dust cover	S4000-01-04-032
37	Shear box anti-wearing block	S4000-01-04-035
38	block in shear box	S4000-01-04-046
39	Cross-shaped shear stand rail	S4000-01-04-036
40	right shear stand	S4000-01-04-027
41	right outer former guide	S4000-01-04-063
42	Right low shear	S4000-01-04-064
43	RH shear installing cover	S4000-01-04-060
44	Connection head cover	S4000-01-04-042
45	screw 10-32UNF*1/2	S4000-01-04-041
46	ball	S4000-01-04-044
47	Cross-shaped shear stand	S4000-01-04-040
48	Block outside shear box	S4000-01-04-043
49	Outer former limit block	S4000-01-04-038
50	Shear box cover	S4000-01-04-033
51	Shear box cover up and down adjustable stand	S4000-01-04-034
52	left shear	S4000-01-04-047
53	left outer former	S4000-01-04-048
54	left pusher tip	S4000-01-04-049
55	anchor ear D12	S4000-01-11-037
56	16 toothed chaine wheel	S4000-01-11-034
57	Bearing TLA1212	S4000-01-11-038
58	feederchain wheel fulcrum bar 1	S4000-01-11-006
59	POM bushing 2	S4000-01-11-026
60	Press cover on shear cap	S4000-01-04-039
61	Right pusher tip	S4000-01-04-050
62	right outer former	S4000-01-04-051
63	Right shear	S4000-01-04-052
64	Round bar	S4000-01-04-028
65	bearing 6200ZZ	S4000-01-04-087

66	cup head screw M5×25	
67	cup head screw M4×6	
68	cup head screw M5×38	
69	cup head screw M10×30	
70	cup head screw M5×20	
71	cup head screw M5×12	
72	cup head screw M5×16	
73	cup head screw M3×10	
74	Cotter $\Phi 5.3$	
75	Locating stud M5×254	
76	cup head screw M5×6	
77	cup head screw M5×13	
78	cup head screw M5×10	




Centering Assembly Picture



Centering Assembly Break down chart

Centering Assembly component list		
No.	Name	Part #
1	centering horizontal supporting bar	S4000-01-05-039
2	centering vertical supporting bar	S4000-01-05-038
3	air cylinder	CJP2B10-5D
4	Up and down air cylinder housing	S4000-01-05-048
5	Float connector	JA10-4-070
6	centering stand holder	S4000-01-05-036
7	Mini stainless steel guide rail	MR9MNSS1V1NL40-10-10
8	Centering stand	S4000-01-05-031
9	right and left air cylinder housing	S4000-01-05-037
10	air cylinder	CJP2B10-5D
11	centering spring	S4000-01-05-047
12	centering piece1	S4000-01-05-032
13	pin roll	S4000-01-05-035
14	Centering plate	S4000-01-05-034


15	Centering piece 2	S4000-01-05-033
16	Air joint	PL4-M3



Jump wire box Assembly break down chart


Jump wire Assembly component list		
No.	Name	Part #
1	jump wire box aluminium block 5	S4000-01-06-045
2	jump wire box aluminium block 1	S4000-01-06-041
3	jump wire conditioning(straight) device connecting block	S4000-01-06-034
4	Roller seat locating block	S4000-01-06-038
5	Roller seat 2	S4000-01-06-039
6	Roller seat 4	S4000-01-06-040
7	Roller locating bloc	S4000-01-06-033
8	Small wheel	S4000-01-06-018
9	bearing 684Z	S4000-01-06-061
10	roller screw	S4000-01-06-037
11	Roller seat 3	S4000-01-06-036
12	Locating stud	S4000-01-06-031
13	jump wire pipe	S4000-01-06-032
14	Shield piece	S4000-01-06-047
15	3/16 loose-proof nut	S4000-03-06-014
16	jump wire box aluminium block 4	S4000-01-06-044
17	jump wire gear 2	S4000-01-06-049
18	bearing MF105ZZ	S4000-01-06-062
19	gear tighten screw	S4000-01-06-053
20	jump wire box aluminium block 3	S4000-01-06-043
21	aluminium block 2	S4000-01-06-052
22	jump wire gear 1	S4000-01-06-050
23	jump wire box aluminium block 2	S4000-01-06-042
24	bearing F699ZZ	S4000-01-06-063
25	jump wire box main shaft	S4000-01-06-046
26	feed motor housing	S4000-01-06-028
27	feed motor connector	S4000-01-06-027
28	feed motor connector anchor ear	S4000-01-06-026
29	100W servo motor	

30	jump wire spring	S4000-01-06-030
31	cup head screw M5×20	
32	round cup screw M4×12	
33	round cup screw M4×10	
34	cup head screw M4×12	
35	set M4×5	
36	cup head screw M5×25	
37	round cup screw M5×20	



Machine Visual break down chart


Machine Visual component list		
No.	Name	Part #
1	camera stand up and down adjusting guide rail	S4000-01-13-001
2	camera stand	S4000-01-13-002
3	camera	S4000-01-13-006
4	camera flashlight stand	S4000-01-13-003
5	camera cover	S4000-01-13-004
6	round cup screw M4×10	
7	round cup screw M5×16	
8	cup head screw M3×12	



C Shaft Assembly Break down chart


U shaft Assembly component list		
No.	Name	Part #
3	Machine stand seat pad 3	S4000-01-01-022
4	Machine stand big square tube	S4000-01-01-008
5	Machine stand big square tube seat pad1	S4000-01-01-012
6	Machine stand big square tube seat pad2	S4000-01-01-013
7	X shaft motor housng	S4000-01-02-036
8	XY motor synchronizing wheel anchor ear	S4000-01-02-037
9	U motor synchronizing wheel	S4000-01-02-023
10	400W servo motor	
11	U zero position synchronizing wheel	S4000-01-03-002
12	Low U stand	S4000-01-03-005
13	U zero position bar	S4000-01-03-016
14	low U connecting rod	S4000-01-03-006
15	synchronizing wheel D10	S4000-01-03-008
16	anchor ear D14	S4000-01-03-009
17	Shaft joint	S4000-01-03-020
18	U zero position synchronizing wheel housing	S4000-01-03-014
19	U zero position bar locating anchor ear	S4000-01-03-017
20	U zero position limit piece	S4000-01-03-018
21	up U right hand stand	S4000-01-03-010
22	Bearing 608ZZ	S4000-01-03-025
23	U zero position driving synchronizing wheel	S4000-01-03-003
24	up U left hand stand	S4000-01-03-013
25	up U connecting rod	S4000-01-03-006
26	Head seat pad	S4000-01-01-014
27	jump wire pipe housing	S4000-01-06-025
28	U zero position switch holder	S4000-01-03-015
29	optoelectronic switchEE-SX670	
30	Bearing BA66Z	S4000-01-03-024
31	up U right hand stand housing	S4000-01-03-011
32	Bearing 608ZZ	S4000-01-03-025
34	U zero position limit piece	S4000-01-03-019

35	timing belt 180XL*10	S4000-01-03-022
36	timing belt 150XL*10	S4000-01-03-021
37	timing belt 270XL*10	S4000-01-03-023
38	feed pipe $\phi 6 \times \phi 5 \times 500$	S4000-01-06-054




Workbench X Assembly Break down chart

Workbench X Assembly component list		
No.	Name	Part #
1	baseboard	S4000-01-01-005
2	X rail holder	S4000-01-02-014
4	Slider bearing	S4000-01-02-041
5	X sliderseat pad	S4000-01-02-024
6	XY rail	S4000-01-02-012
7	X impact-proof stop block	S4000-01-02-008
9	X bearing housing1	S4000-01-02-015
10	XY bearing cap	S4000-01-02-027
11	Bearing 7202CYP4	S4000-01-02-042
12	XY lead screw synchronizing wheel anchor ear	S4000-01-02-021
13	XY lead screw synchronizing wheel	S4000-01-02-022
14	X bearing housing 2	S4000-01-02-019
15	bearing 6202ZZ	S4000-01-02-043
16	XY zero position limit housing	S4000-01-02-026
17	Optoelectronic switch EE-SX670	
18	XY shaft lead screw	S4000-01-02-035
19	X shaft motor housing	S4000-01-02-036
20	XY motor synchronizing wheel	S4000-01-02-023
21	XY motor synchronizing wheel anchor ear	S4000-01-02-037
22	400W servo motor	
23	lead screw nut	S4000-01-02-028
24	cup head screw M6×25	
25	cup head screw M5×25	
26	cup head screw M6×35	
27	cup head screw M12×35	
28	cup head screw M5×16	
29	cup head screw M5×5	
30	cup head screw M4×20	




Housing Assembly Picture



Housing Assembly Break down Chart

housing component list		
No.	Name	Part #
1	U bearing cap	S4000-01-12-001
2	bearing with snap spring	5200ZZ
3	U shaft left and right spin lead screw	S4000-01-04-017
4	housing frame	S4000-01-12-002
5	bearing	6200ZZ
6	lead screw nut	S4000-01-04-018
7	Long straight liner guide rail	S4000-01-12-053
8	LH aluminum block fixed on lead screw	S4000-01-12-013
9	RH aluminum block fixed on lead screw	S4000-01-12-012
10	RH clinch housing	S4000-01-12-003
11	Short straight liner guide rail	S4000-01-12-054
12	LH clinch seat	S4000-01-12-005
13	RH clinch seat	S4000-01-12-006
14	Hard steel shaft fixed seat	S4000-01-12-038
15	Clinch up and down slider bar	S4000-01-12-011
16	slider to locate clinch	S4000-01-12-009
17	housing driven synchronizing wheel	S4000-01-12-036
18	anchor ear D12	S4000-01-12-037
19	housing inspection piece	S4000-01-12-042
20	timing belt	116XL*12
21	housing motor synchronizing wheel	S4000-01-12-039
22	400W motor synchronizing wheel anchor ear	S4000-01-02-037
23	housing motor synchronizing wheel	S4000-01-12-039
24	400W servo motor	MHMD042P1U
25	nut M10*1	S4000-01-12-043
26	bearing	6900ZZ
27	optoelectronic switch	EE-SX671
28	Straight line bearing	LMK13LUU
29	Hard steel shaft	S4000-01-12-052
30	housing cam shaft	S4000-01-12-033
31	housing cam	S4000-01-12-034
32	housing cam shaft housing	S4000-01-12-032
33	Spring hanging	S4000-01-12-040
34	SPRING	S4000-01-12-044
35	bearing	CR10-1
36	LH clinch housing	S4000-01-12-004


37	housing frame seat pad	S4000-01-12-031
----	------------------------	-----------------



Clinch Break down Chart

Clinch component list		
No.	Name	Part #
1	Piston travel limit tighten nut	S4000-01-12-023
2	piston travel limit block	S4000-01-12-019
3	inner buffering glue	S4000-01-12-025
4	clinch air cylinder cap	S4000-01-12-015
5	seal ring $\phi 7.5 \times 1.8$	
6	seal ring $\phi 31.5 \times 1.8$	
7	piston rod	S4000-01-12-020
8	piston nut	S4000-01-12-021
9	piston	S4000-01-12-022
10	seal ring $\phi 28 \times 3.55$	
11	seal ring $\phi 12.2 \times 2.65$	


12	clinch air cylinder	S4000-01-12-014
13	Elasticity cylindrical pin ϕ 3.2	S4000-01-12-056
14	elasticity cylindrical pin ϕ 1.6	S4000-01-12-055
15	Triangle shear cover	S4000-01-12-016
16	Movable shear	S4000-01-12-017
17	Triangle shear cover	S4000-01-12-018
18	Debris dispose pipe	S4000-01-12-008
19	Cap to press on debris dispose pipe	S4000-01-12-024
20	seal ring ϕ 5*2	
21	Air connector PC06-01	
22	cup head screw M4 \times 16	
23	cup head screw M3 \times 10	
24	flat head screw M3 \times 8	



Workbench Y Assembly Break down chart

Workbench Y Assembly component list		
No.	Name	Part #
1	workbench middle aluminium plate	S4000-01-02-002
2	left hand flatten alumnum stick	S4000-01-02-005
3	right hand flatten alumnum stick	S4000-01-02-006
4	Y rail housing	S4000-01-02-013
5	XY rail hard steel shaft	S4000-01-02-012
6	Slider bearing	S4000-01-02-041
7	Optoelectronic switch EE-SX670	
8	Yshaft nut locating seat	S4000-01-02-020
9	Y impact-proof locating block	S4000-01-02-007
10	impact-proof rubber	
11	X.Y zero position limit seat	S4000-01-02-026
12	Y limit switch piece	S4000-01-02-030
13	Y drag chain installing board	S4000-01-02-029
14	Y impact-proof stop block	S4000-01-02-010
15	Y bearing housing1	S4000-01-02-018
16	Bearing 7202CYP4	S4000-01-02-042
17	XY lead screw	S4000-01-02-035
18	XY bearing cap	S4000-01-02-027
19	Y bearing housing2	S4000-01-02-019
12	XY lead screw synchronizing wheel anchor ear	S4000-01-02-021
21	XY lead screw synchronizing wheel	S4000-01-02-022
22	Rear flatten alumnum stick	S4000-01-02-004
23	400W servo motor	
21	XY motor synchronizing wheel anchor ear	S4000-01-02-037
25	XY motor synchronizing wheel	S4000-01-02-023
26	Y shaft motor housing	S4000-01-02-036
27	Middle flatten alumnum stick	S4000-01-02-003
28	bearing 6200ZZ	S4000-01-02-043
29	Y limit switch piece	S4000-01-02-031

30	nut M14X1	S4000-01-02-028
31	timing belt 161L*10	S4000-01-02-044
32	cup head screw M4×20	
33	cup head screw M4×25	
34	cup head screw M4×16	
35	round head screw M5×12	
36	round head screw M5×10	
37	cup head screw M5×16	
38	cup head screw M6×35	
39	round head screw M5×25	
40	Locating pin 3/16"×20	
41	cup head screw M5×5	




Workbench Board and turn plateMechanism break down chart

workbench board and turn plateMechanism component list		
No.	Name	Part #
1	Workbench	S4000-01-07-001
2	workbench rear aluminum bar	S4000-01-07-004
3	workbench RH alumnum bar	S4000-01-07-002
4	turn table motor housing	S4000-01-07-023
5	turn table motor belt wheel XL16	S4000-01-07-036
6	bearing F606ZZ	S4000-01-07-056
8	turn table driver belt wheel XL16	S4000-01-07-037
9	turn table air cylinder install alumnium block	S4000-01-07-005

11	workbench LH flatten aluminium stick	S4000-01-07-003
12	Y impact-proof locating block	S4000-01-02-009
13	impact-proof rubber	S4000-01-02-045
15	Y shaft nut locating seat	S4000-01-02-017
16	turn table motor	
17	round turn plate	S4000-01-07-006
18	turn plate lock ejector rod	S4000-01-07-008
19	turn plate lock mainblock	S4000-01-07-009
20	RH turn plate stop locking	S4000-01-07-010
21	LH turn plate stop locking	S4000-01-07-011
22	turn plate stop locking baffle block	S4000-01-07-012
23	turn plate stop locking block PIN	S4000-01-07-013
24	turn plate stop locking installing PIN	S4000-01-07-014
25	SPRING	S4000-01-07-015
26	lock elastic bolt cover	S4000-01-07-016
27	lock air cylinder connector	S4000-01-07-017
28	SPRING	S4000-01-07-018
29	turn table driving wheel axle	S4000-01-07-019
30	turn table driving wheel socket	S4000-01-07-020
31	turn table driving wheel stand slider	S4000-01-07-021
32	turn table driving wheel stand slider cover	S4000-01-07-022
33	turn plate driving air cylinder	S4000-05-01-013
34	turn table lock air cylinder housing	S4000-01-07-025
35	platy bearing $\phi 6.35 * \phi 17.02$	S4000-01-07-052
36	turn table lock clamp	S4000-01-07-027
37	turn table locating piece for four corners	S4000-01-07-028
38	turn table locating sensor seat	S4000-01-07-029
39	turn table jig locating PIN	S4000-01-07-030
40	turn table lock air cylinder	S4000-01-07-025
41	turn table locating bearing for four corners	S4000-01-07-032
42	turn table rotate rail bearing housing	S4000-01-07-033


43	bearing CR12	S4000-01-07-054
44	Bearing CR10-1	S4000-01-07-055
45	turn table lock device cover	S4000-01-07-034
46	turn plate electromagnetic valve	S4000-05-01-007
50	magnet	S4000-01-07-051
51	driving synchronizing wheel rubber	S4000-01-07-031
52	D6.35 anchor ear	S4000-01-07-026
53	PIN to connect and lock air cylinder	S4000-01-07-035
54	Air connector PC06-M5	
55	Air connector PC04-M5	
56	Air connector PC04-M3	
57	cup head screw M6×20	
58	cup head screw M5×20	
59	cup head screw M5×10	
60	Cup head screw M4×8	
61	cup head screw M6×25	
62	cup head screw M4×10	
63	cup head screw M5×25	
64	cup head screw M3×25	
65	round cup screw M5×20	
66	cup head screw M4×12	

1	Carrier clmap shaft	S4000-01-10-005
2	Right hand carrier clmap	S4000-01-10-002
3	left hand carrier clmap	S4000-01-10-003
4	carrier clmap piece	S4000-01-10-004
5	carrier clmap spring	S4000-01-10-006



Conjunction break down chart —

Conjunction component list 1		
No.	Name	Part #
1	motor holding stand	S4000-02-02-008
2	Butt joint machine stand	S4000-02-01-005
3	Butt joint connecting board	S4000-02-01-014
4	Machine stand connecting block	S4000-02-01-003
5	Connection baseboard	S4000-02-01-001
6	Right angle locating seat	S4000-02-01-004
7	connect panel	S4000-02-01-002
8	cup head screw M6×20	
9	cup head screw M8×35	
10	cup head screw M10×80	
11	Locating pin	S4000-02-01-016




Conjunction Break down picture 2


Conjunction component list 2		
No.	Name	Part #
1	750W servo motor	
2	Planetary speed reducer	DH090L1-10-19-70

3	750W motor holding	S4000-02-02-011
4	shaft joint	LK11-68K-20.64-20
5	Driving sprocket shaft	S4000-02-02-013
6	Driving synchronizing wheel	S4000-02-02-007
7	40 toothed chaine wheel	S4000-02-03-009
8	Carrier clamp open wheel	S4000-02-03-008
9	H shaft optoelectronic inspection holder2	S4000-01-04-015
10	optoelectronic switchEE-SX671	
11	10 toothed inspection plate	S4000-02-02-026
12	Rear aluminium plate	S4000-02-02-001
13	bearing BA1310ZZ	S4000-02-02-045
14	Rear clapboard 2	S4000-02-02-003
15	front aluminium plate	S4000-02-02-004
16	Waste leg hopper	S4000-03-08-029
17	Front clapboard 2	S4000-02-02-039
18	Front clapboard 1	S4000-02-02-038
19	Baffle board for waste material	S4000-02-02-041
20	Shaft locating board	S4000-02-02-037
21	Front spacer column	S4000-02-02-040
22	material pressing piece left hand installation block	S4000-02-05-011
23	spacer block	S4000-02-05-012
24	arched material pressing piece	S4000-02-05-003
25	seat pad	S4000-02-05-016
26	material pressing piece locating holder	S4000-02-05-017
27	material shielder installation block	S4000-02-04-004
28	Left hand baffle piece	S4000-02-04-001
29	material pressing piece right hand installation block	S4000-02-05-019
30	right hand baffle piece	S4000-02-04-002
31	Rear clapboard 1	S4000-02-02-002
32	Rear ear	S4000-02-02-005
33	Locating block to tighten timing belt	S4000-02-02-033


34	Adjustable block to tighten timing belt	S4000-02-02-034
35	bearing TLA1010Z	S4000-02-02-046
36	aluminium column	S4000-02-02-036
37	Headed ejection pin $\phi 10 \times 104$	S4000-02-02-035
38	Timing belt HTD520-5M*28	S4000-02-02-044
39	synchronizing wheel locating holder	S4000-02-02-029
40	Driven sprocket wheel shaft	S4000-02-02-014
41	driven synchronizing wheel	S4000-02-02-006
42	material catching wheel	S4000-02-03-003
43	36 toothed chaine wheel	S4000-02-02-015




Partial picture of Sequencer



Dispenser Driving Assembly picture 1






Dispenser Driving Assembly picture 2




Dispenser Driving Assembly Break down chart

Dispenser Driving Assembly component list		
No.	Name	Part #
1	air cylinder install housing	S4000-03-06-001
2	air cylinder connecting rod	S4000-03-06-010
3	air cylinder shaft anchor ear	S4000-03-06-007
4	Station coupling pin	S4000-03-06-006
5	station shaft joint 1	S4000-03-06-004
6	Uni-directional bearing RC-061008	S4000-03-06-013
7	station shaft joint 2	S4000-03-06-005
8	short air cylinder shaft	S4000-03-06-002
9	air cylinder connecting rod pin	S4000-03-06-012
10	air cylinder connector	S4000-03-06-011
11	air cylinder	
12	air cylinder install right angle housing	S4000-03-06-008
13	Steel bushing	S4000-03-06-009
43	Loose-proff nut	S4000-03-06-014
44	1MM bolt	S4000-03-06-016
45	cup head screw M8*20	
46	cup head screw M5*25	
47	cup head screw M6*25	
48	nut M8	





Picture of Dispenser



Dispenser Break down chart

Dispenser component list		
No.	Name	Part #
1	Station body	S4000-03-05-001
2	Prositive and reverse thread rod	S4000-03-05-024
3	inner component glue track	S4000-03-05-031
	outer component glue track	S4000-03-05-032
4	Station maine driver rod	S4000-03-05-023
5	Station driven rod	S4000-03-05-026
6	left hand station component gear	S4000-03-05-003
	right hand station component gear	S4000-03-05-004
8	flanged shaft sleeve	S4000-03-05-027
9	Prositive and reverse thread stem	S4000-03-05-021
10	guide rail gear outside station	S4000-03-05-005
	inner guide rail gear inside station	S4000-03-05-006
11	outer gear shear	S4000-03-05-008
	inner gear shear	S4000-03-05-007
12	Feed parallel wheel	S4000-03-05-002
13	Driven gear	S4000-03-05-010
14	Front stainless steel bend rail fulcrum bar	S4000-03-05-025
15	Front inner stainless steel bend rail	S4000-03-05-013
	Front outer stainless steel bend rail	S4000-03-05-014
16	Space spring	S4000-03-05-028
17	stop body	S4000-03-05-020
18	Station outer shear	S4000-03-05-011
	Station innershear	S4000-03-05-012
19	anchor ear	S4000-03-05-036
20	Main driving gear	S4000-03-05-009
21	Rear outer bend rail	S4000-03-05-015
	Rear inner bend rail	S4000-03-05-016
22	stop pulley	S4000-03-05-019
23	Stop spring	S4000-03-05-037
24	Stop body locating bolt	S4000-03-05-017
25	Short rubber cover	S4000-03-05-034
26	Station main driver rod stem	S4000-03-05-022
27	Rear stainless steel guide rail lock plate	S4000-03-05-030
28	Station shear seat pad	S4000-03-05-029
29	Long rubber cover	S4000-03-05-035
30	set screw M3*5	
31	cup head screw M4*12	
32	set screw M4*5	