



Southern Machinery Sales and Service Co., Limited


CWEF-JE12/16/24 Description File







II . Key Manual




TEL: +8613602562576; Email: info@SMThelp.com website:www.SMThelp.com



Southern Machinery Sales and Service Co., Limited


III. Install the tape




1.Put the tape to reel holder as




2. Open protect clasp, put the tape to get through tape guide assv.




3.Remove the membrane,install the tape well.




4.Put the tape guide assy back, closed the protect clasp.



5.Drag the membrane,get through the roller. **Notice: the film must be held tight.**




6.Press the lever assy push in the excess membrane.



7.Install the feeder locked on the seat and power on it.



8.Open tape guide assy,drag the membrane get through the roller,locked the protect clasp.



9.Ensure the gear well,press buttom to push in the excess membrane.

TEL: +8613602562576; Email: info@SMThelp.com website:www.SMThelp.com