



Features:

1. Each solder paste placement slot has an independent LED display time controller. After setting the time the solder paste will be fixed in the tank and sink automatically, also it will release automatically when time is over.

2. With "first in,first out" function, for example, we warm up paste A,B,C,D in a row, when all of the paste finished, need take

out of the bottles ranks A,B,C,D, if you don't take the A out, then you can't take B,C, or D.


3. In the case of out of power accidentally, even if not reach set time, solder paste bottle will automatically pop up.

4. Equipped with an automatic alarm system, when reaching the setting time, this machine will automatically alarm. Also, there is an


emergency stop button for emergency suitation, easy operation and security.6. This automatic solder paste warm up machine has 4 tanks,can warm up 4 bottles paste at the same time,if need more tanks, can be



Parts description



Time setting



www.smthelp.com






Model Power Air presure Capacity Dimensions Weight

S-SPW01 1P 220V OR 110V 50/60HZ 5KG 500g*4 units OR customized L500*W300*H230 (MM) Approx.15KGS

www.smthelp.com



WELCOME INQUIRY



www.smthelp.com