



## Southern Machinery Sales and Service Co. Limited

Add :Rm 1806,Block 3, Jinyun COFCO, Qianjin 2 Road,Xixiang,Baoan District, Shenzhen City, China  
TEL: 0755-83203237; FAX:0755-23240492 website:www.smthelp.com

# LED control interface

Url: /ledcontrol      Request type: httpost  
storage location code: 0010001    001 smart rack ID    0001 storage location code

```
json:{
  mac:""//equipment mac address lower case
  ledsmsg:[{
    id:1,//light position
    lighttype:1,//lighting type 0:off 1:on 2:flicker
    color:'1',//color multicolor flicker:'1234567' :red, yellow,blue, green, teal,
purple, white
    times:0,//flick times or light time(s) , -1:lighting type is flicker or unlimited times
when light on
  },{
    id:2,//light position
    lighttype:2,///lighting type 0:off 1:on 2:flicker
    color:2,//color
    times:10,//flicker times
  ]
}
```

```
Json{
result:true //bool,
msg:""
}
```



## **Southern Machinery Sales and Service Co. Limited**

Add :Rm 1806,Block 3, Jinyun COFCO, Qianjin 2 Road,Xixiang,Baoan District, Shenzhen City, China  
TEL: 0755-83203237; FAX:0755-23240492 website:www.smthelp.com

# **Acquire smart rack Mac address and IP address**

Url: /getmacip request type httpget



## Southern Machinery Sales and Service Co. Limited

Add :Rm 1806,Block 3, Jinyun COFCO, Qianjin 2 Road,Xixiang,Baoan District, Shenzhen City, China  
TEL: 0755-83203237; FAX:0755-23240492 website:www.smthelp.com

# LED seven color light on in circulation

Url: /ledcheck request type httpost

```
json:{  
  mac: "",//equipment control mac address  
},
```



## Southern Machinery Sales and Service Co. Limited

Add :Rm 1806,Block 3, Jinyun COFCO, Qianjin 2 Road,Xixiang,Baoan District, Shenzhen City, China  
TEL: 0755-83203237; FAX:0755-23240492 website:www.smthelp.com

# Set smart rack left and right separation number

Url: /setmidnum request type httpost

```
json: {  
  mac: "",//equipment control mac address  
  num: 20,//left and right separation number  
},
```



## Southern Machinery Sales and Service Co. Limited

Add :Rm 1806,Block 3, Jinyun COFCO, Qianjin 2 Road,Xixiang,Baoan District, Shenzhen City, China  
TEL: 0755-83203237; FAX:0755-23240492 website:www.smthelp.com

# Set the url of the server smart rack upgrading mac and ip

Url: /setserverip request type http post

```
json: {  
  ip: "http://192.168.1.1:80/api/shelfservice", //url post requested by server  
},
```

Request type sent by Raspberry Pi: Post



## Southern Machinery Sales and Service Co. Limited

Add :Rm 1806,Block 3, Jinyun COFCO, Qianjin 2 Road,Xixiang,Baoan District, Shenzhen City, China  
TEL: 0755-83203237; FAX:0755-23240492 website:www.smthelp.com

# Set the total storage location amount of the smart rack

Url: /settotalnum request type httppost

```
json: {  
  mac: "",//equipment control mac address  
  num: 20,//total storage location amount  
},
```

# All lights on and off

Url: /allledcontrol request type http post

```
json: {  
  mac: "",//equipment control mac address  
  onoff: 0,//on---1off ---0  
  color:1,//color 1-7  
  sceonds:1,//control time -1 unlimited unit (s)  
},
```



## Southern Machinery Sales and Service Co. Limited

Add :Rm 1806,Block 3, Jinyun COFCO, Qianjin 2 Road,Xixiang,Baoan District, Shenzhen City, China  
TEL: 0755-83203237; FAX:0755-23240492 website:www.smthelp.com

# Authorization

Url: /settotalnum request type httpost

```
json: {  
  mac: "",//equipment control mac address  
  key: "",//secret key  
},
```