Chrome-Plated Handcart

- Convenient storage tray, both sides can be accessed
- Escort the material tray
- Can add layer or reduce layer accessories can be added or subtracted









Unimodal net

Bimodal network

Bimodal network

Bimodal network



Bimodal network

Put the diameter of 180mm plate Peak grid distance 20mm Specifications: 907*457*, 82 grids 1215*457, 112 grids



www.smthelp.com





The cell has a large capacity

Unimodal net

Put the diameter of 330mm plate

save space

1215*457, 23 grids Peak mesh distance 45mm

Make your material tray easy to store at a glance

www.smthelp.com



- According to the number of material plate, free matching,

Specifications: 907*457, 17 grids

Plain net



- Main: 6.0 mm Wave line: 4.5 mm Line: 3.0
- Spacing: 17 mm
- Specification: 907*457 1215* 457

Make your material tray easy to store at a glance



U handle



Humanized and pulled

With it Play a push and pull role It is convenient to use and saves time and effort

www.smthelp.com



Humanized design can be pushed

Durable



is silent and wear-resistant

according to requirements

www.smthelp.com



360 degree rotation universal wheel

3 inch PVC wheel, anti-static wheel can be selected







Installation Instructions



1. Open the top cover and put the wheels on the opposite end of the top cover



3. Intall the clips according to the uniform height



2. Hold the wheel and tube in both hands and use inertia to smash the wheel into the tube



4. Place the mesh side on the ground



上窄

下宽

Note: The convex part of the clip and the groove of the tube need to match to clamp tight



5. Insert the tube into the come sleeve of the network piece respectively

Note: The clips cannot be placed upside down



6. Insert the 4 pipes well and tighten them tightly

www.smthelp.com





7. After standing up, install the clip on the same level and height at the required position



8. Set the second mesh piece from the top of the tube, and press it tightly



9. Repeat steps 7 and 8 to complete the installation of the remining mesh

Note:

- 1. After the wheel installed, the top cover should be recovered
- 2. If there are no wheels, skip steps 1 and 2
- 3. If there is a handle, it is also set up according to the method of installing the net.

Packing & Delivery



Packing Details: Packing, solid carton, can print your logo outside.



www.smthelp.com



Delivery Details: 3-15 days after get the deposit.



Shenzhen Southern Machinery Sales And Service Co.,Ltd

- 1. One-stop Shopping, Providing Quality Smt Peripheral Equipment,
- 2. Experienced Engineers Provide After-sales Installation & Training Services. 3. Customized Solutions.
- 4. All Equipment Has Ce Certification, UI Certification. RoHS Certification 5. Provide Sea Freight, Customs Clearance Delivery Service. Buying Ai Smt Accessories Free Shipping.

OUR CLIENTS

Schneider JABIL FI-N PHILIPS LITEON[®] FOXCON



